
OPERATING MANUAL FOR

MiniDMXter4™
Software Version 3.00
ShowSaver™
RDM controller V1.00
FOR HARDWARE FD DMX-6

Goddard Design Co.
51 Nassau Avenue
Brooklyn, NY 11222
(718)599-0170
(718)599-0172 fax
<http://www.goddarddesign.com>
sales@goddarddesign.com

Copyright 1991- 2010 by Goddard Design Co.
L:\word_pl\wp6doc\dmx-man\mini4_man1.wpd

3/17/10

TABLE OF CONTENTS

INTRODUCTION 1

USITT DMX512-A AND THIS SOFTWARE 1

HARDWARE FEATURES OF THE MiniDMXter4 1

0.0 SAFETY WARNING 1

 0.1.1 Use a Blanking Plug in Unused DMX Connectors 2

0.2 GETTING STARTED - QUICKLY 2

1 CONVENTIONS 2

 1.1 KEY CONVENTIONS 2

 1.1.1 ACTION ON KEY UP 2

 1.1.2 <BLUE> 2

 1.1.3 THE <BACK> KEY 3

 1.1.4 <RED> 3

 1.1.5 <UP>, <DOWN> 3

 1.1.5.1 **Bumping a Numeric Value to Minimum or Maximum:** 3

 1.1.5.2 **Bumping a Numeric Value to Half:** 3

 1.1.5.3 **Auto-incrementing a Numeric Value:** 3

 1.1.6 <LEFT>, <RIGHT> 3

 1.1.6.1 **Changing a Slot Number by One:** 4

 1.1.6.2 **Auto-increment The Slot Number:** 4

 1.1.6.3 **Jumping the Slot Number by 10:** 4

 1.1.6.5 **Auto-increment the Slot Number by 10:** 4

 1.1.6.6 **Forcing the Slot Number to One:** 4

 1.1.7 <UP><RIGHT> Cycles Through Number Formats 4

 1.1.8 <BLUE> As a Shift Key 4

 1.2 DISPLAY CONVENTIONS 4

 1.3 NUMBER CONVENTIONS 4

 1.3.1 Default Display Format 4

2 TURNING THE UNIT OFF AND ON 5

 2.1 IF THE UNIT WILL NOT TURN ON 5

 2.2 RESETTING TO FACTORY DEFAULTS 5

 2.3 OWNER IDENTIFICATION MESSAGE (OPTIONAL) 5

 2.4 THE DISPLAY BACKLITE 5

3 MAIN MENU 6

4 TRANSMIT DMX 6

 4.0.1 If a Non-zero START Code Is Set 6

 4.0.2 If a Non-standard ‘Flavor’ Is Set 6

 4.1 ADJUSTING ONE SLOT 6

 4.2 REENTERING ADJUST ONE 7

| | | |
|--------|---|----|
| 4.3 | AUTOFADING ONE SLOT | 7 |
| 4.4 | CLEARING THE SNAPSHOT | 7 |
| 4.5 | TAKING NEW SNAPSHOT | 8 |
| 4.5.1 | Actions That Overwrite or Erase a Snapshot | 8 |
| 4.6 | SEND/EDIT SNAPSHOT | 8 |
| 4.6.1 | Searching for the next Slot with Level | 9 |
| 4.6.2 | Re-entering Send/Edit Snapshot | 9 |
| 4.6.3 | Clearing the Snapshot Within Send/Edit | 9 |
| 4.7 | SEND FLAVOR | 9 |
| 4.8 | BACK TO MAIN MENU | 10 |
| 4.9 | CHANGING THE START CODE | 10 |
| 4.9.1 | MAB Accuracy Vs. START Code | 11 |
| 4.10 | SETTING THE MINIMUM LEVEL FOR SEARCHES | 11 |
| 4.11 | ADVANCED TRANSMIT ROUTINES | 11 |
| 4.11.1 | Adjust All Slots | 11 |
| 4.11.2 | DMX512 TEST PACKET - HEX 55 | 11 |
| 4.11.3 | Sending Text Packets | 12 |
| 5 | RECEIVE DMX512 | 12 |
| 5.0.1 | If a Non-zero START Code Is Set | 13 |
| 5.1 | VIEW LEVELS | 13 |
| 5.1.1 | Display and Timeout Rules | 13 |
| 5.1.2 | <UP> Clears the Display Buffer and Restarts Receive | 13 |
| 5.1.3 | <DOWN> Restarts the Receiver | 14 |
| 5.1.4 | Received Slot Summary Display | 14 |
| 5.1.5 | Data Error While Viewing Levels | 14 |
| 5.2 | VIEW LEVEL GRAPHICALLY | 14 |
| 5.3 | VIEW ON USB TERMINAL | 14 |
| 5.4 | VIEW PARAMETERS | 15 |
| 5.4.1 | Break Length | 15 |
| 5.4.2 | Mark after Break Length | 16 |
| 5.4.3 | List Received START Codes | 16 |
| 5.4.4 | # of Slots per Packet | 16 |
| 5.4.5 | Interslot Time in μ s | 16 |
| 5.4.6 | MARK BEFORE BREAK in μ s | 16 |
| 5.4.7 | MARK AFTER START CODE in μ s | 16 |
| 5.4.8 | Average Routines for 5.4.5 - 5.4.6 - 5.4.7 | 17 |
| 5.4.9 | Break-to-break Time | 17 |
| 5.4.10 | Updates per Second | 17 |
| 5.5 | RETURN TO MAIN MENU | 17 |
| 5.6 | CHANGING THE START CODE | 17 |
| 5.7 | SETTING THE MINIMUM LEVEL FOR SEARCHES | 18 |
| 5.8 | DMX512 PARAMETERS NOT CHECKED | 18 |

| | |
|--|----|
| 5.9 RECEIVE TEXT PACKETS | 18 |
| 5.9.1 Displayed Character | 19 |
| 6 CABLE TESTER | 19 |
| 6.1 DOUBLE ENDED CABLE TEST | 19 |
| 6.1.1 Ending Cable Test | 20 |
| 7 SETUP OPTIONS | 21 |
| 7.1 AUTO SHUTDOWN TIMER | 21 |
| 7.1.1 DISABLING THE AUTO SHUTDOWN TIMER | 21 |
| 7.2 BACK-LITE OFF OPTION | 21 |
| 7.3 DISABLING THE BACKLITE TIMER | 21 |
| 7.4 NUMBER FORMAT OPTION | 21 |
| 7.5 OPEN LINE DETECTOR OPTION | 22 |
| 7.6 ENABLE BUMP ALL | 22 |
| 7.7 COPYRIGHT NOTICE - Author Credits | 22 |
| 7.8 FIRMWARE BUILD DATE | 22 |
| 7.9 FIRMWARE CHECKSUM | 22 |
| 7.10 CLEAR MEMORIES | 22 |
| 7.10.1 ERASE EEPROM | 22 |
| 7.10.2 ERASE FLASH | 22 |
| 7.10.3 CLEAR RAM AND SHUT DOWN | 23 |
| 8 FLICKER FINDER | 23 |
| 8.1 RE-ENTERING FLICKER FINDER | 24 |
| 8.2 TECHNICAL NOTES ON FLICKER FINDER | 25 |
| 8.2.1 Low Battery Warnings During Flicker Finder | 25 |
| 9 SHOWSAVER™ | 25 |
| 9.0.1 ShowSaver , Conventions and Structure | 26 |
| 9.0.2 Selecting Playback or Record | 26 |
| 9.1 PLAYBACK | 26 |
| 9.2 DMX MONITOR MODE | 26 |
| 9.2.1 When the Monitor Mode Detects a Failure | 27 |
| 9.2.2 If Auto Start Is Disabled | 27 |
| 9.2.3 If Auto Start Is Enabled | 27 |
| 9.2.4 Now That You Are in Play Back Mode | 27 |
| 9.3 ABOUT PLAYBACK | 27 |
| 9.3.1 The Playback Display | 28 |
| 9.3.2 Keys Used in Playback | 28 |
| 9.3.3 The Cross Fader | 28 |
| 9.3.4 The Grand Master | 29 |

| | | |
|---------|--|----|
| 9.3.5 | The Onstage Editor | 29 |
| 9.3.6 | Playback Summary Display | 29 |
| 9.3.7 | Exiting Playback | 29 |
| 9.3.8 | Technical Information about Playback | 29 |
| 9.4 | ShowSaver Start Code & Line Termination | 30 |
| 9.5 | RECORDING SCENES | 30 |
| 9.5.1 | The Scene Select Display | 30 |
| 9.5.2 | Taking the Snapshot | 30 |
| 9.5.3 | Naming the Scene | 31 |
| 9.5.4 | Setting the Fade Time | 31 |
| 9.6 | CLEARING OLD RECORDED SCENES | 31 |
| 9.7 | EDITING RECORDED SCENES | 32 |
| 9.8 | CHANGING THE DEFAULT FADE TIME | 32 |
| 9.9 | LOAD SHOW | 32 |
| 9.10 | STORE SHOW | 32 |
| 9.11 | DELETE STORED SHOW | 32 |
| 9.12 | ERASE CURRENT SHOW | 32 |
| 9.13 | RETURNING TO THE MAIN MENU | 32 |
| 9.14 | PLAYBACK SCENE? | 33 |
| 9.15 | GETTING A SUMMARY OF THE SCENES | 33 |
| 10 | RDM CONTROLLER | 33 |
| 10.1 | Discover Devices | 33 |
| 10.1.1. | Discover Newly Connected Devices | 33 |
| 10.1.2. | Discover All Devices | 33 |
| 10.1.3. | Store Rig | 33 |
| 10.1.4. | Delete Rig | 33 |
| 10.2 | Select Current Device | 34 |
| 10.3 | Device Information | 34 |
| 10.3.1. | Device Model | 34 |
| 10.3.2 | Device Label | 34 |
| 10.3.3 | Manufacturer Label | 34 |
| 10.3.4 | Software Version Number & Label | 34 |
| 10.3.5 | Slot Address & Slot Foot Print | 34 |
| 10.3.6 | Personality Count | 35 |
| 10.3.7 | Sub Device Count & Sensor Count | 35 |
| 10.3.8 | Product Category | 35 |
| 10.3.9 | RDM Protocol Version | 35 |
| 10.3.10 | Device Power State | 35 |
| 10.3.11 | Lamp Hour and Lamp Strikes | 35 |
| 10.3.12 | Lamp State and Lamp On Mode | 35 |
| 10.3.13 | Supported PIDS | 35 |
| 10.4 | Set DMX Address | 36 |

| | |
|---|----|
| 10.5 Set DMX Personality | 36 |
| 10.6 Setup RDM Device | 36 |
| 10.6.1 Set Device Label | 36 |
| 10.6.2 Capture Preset | 36 |
| 10.6.3 | 37 |
| 10.6.4 Warm Reset | 37 |
| 10.6.5 Cold Reset | 37 |
| 10.6.6 Restore to Factory Defaults Need we say more? | 37 |
| 10.7 View Sensors | 37 |
| 10.7.1 Sensor Abbreviation | 38 |
| 10.8 SEND/EDIT DEVICE | 38 |
| 10.9 Edit Null Start Code Data | 39 |
| 10.10 RDM User Options | 39 |
| 10.10.1 Identify Device When Selecting? | 39 |
| 10.10.2 Do You Wish to Retry on Bad or Lost Packets? | 39 |
| 10.10.3 Do You Wish to Ignore Warning Messages On Discovery? | 39 |
| 10.10.4 Controlling When Qued Messages Are Fetched from a Responder | 39 |
| 10.10.5 Interleave Null Start Code Packets? | 39 |
| 11 COLORTRAN PROTOCOL SUPPORT | 39 |
| 12 THE CE MARK | 39 |
| 13 POWERING THE MINI | 40 |
| 13.1 LOW BATTERY WARNINGS / POWER MANAGEMENT | 40 |
| 13.2 Meal Penalty | 40 |
| 13.3 BATTERY OPERATING TIME | 41 |
| 14 MiniDMXter4 TECHNICAL DISCUSSION | 41 |
| 14.1 MiniDMXter4 MAINTENANCE | 41 |
| 14.01 CLEANING | 41 |
| 14.2 SPECIFICATION TABLES | 41 |
| Table 14-2 RECEIVED DMX512 PARAMETERS | 42 |
| Table 14-3 ACCURACY | 42 |
| 14.3 CONNECTOR FUNCTIONS AND CONNECTOR WIRING | 43 |
| 14.3.1 DMX-in | 43 |
| 14.3.2 DMX-out | 43 |
| 14.3.3 Topology for DMX Terminate & DMX Pass Through Modes | 43 |
| 14.3.4 Uses of Pins 4 & 5 | 43 |
| 14.4 THE PERCENT SCALE | 43 |
| 14.5 PERCENT TABLES | 44 |
| 14.6 STANDARDS - DMX512, EIA485 | 45 |
| 14.7 RELEASE NOTES & SOFTWARE VERSION HISTORY | 45 |

| | |
|---|----|
| V3.00 | 45 |
| 15 FCC PART 15 STATEMENT | 45 |
| 16 USB OPERATIONS INCLUDING CODE UPDATES | 46 |
| 16.1 Terminal Emulator Requirements and Recommendations. | 46 |
| 16.2 Using a PC with Routines That Support USB | 46 |
| 16.3 Downloading new operating code to the MiniDMXter4. | 46 |
| 17 THE STRING EDITOR | 47 |
| 18 WARRANTY | 48 |
| APPENDIX A TEXT MESSAGE LISTINGS | 49 |

INTRODUCTION

The MiniDMXter4^{TM1} is a portable test set for checking DMX512 transmission and reception, and for configuring responders using the RDM protocol. It is a replacement for Goddard Design Company's MiniDMXter . If you have used a MniDMXter or a *Lil'*DMXter before you should be right at home; if not, keep reading.

The MiniDMXter4 is battery operated device. It comes with two AA batteries installed. It may also be powered from an external power adaptor, or it may be powered via a computer supporting USB. In this case, it must be directly powered from a computer or a powered hub. If it needs to be programmed from an unpowered hub, see Section 13 for instructions on disabling USB powering.

Your MiniDMXter4 is a software-based machine that uses a menu structure allowing you to step thru its features to get to the test you need to perform. Much of its operation is obvious. The purpose of this manual is to help you run it quickly, and to find the section you want easily. This manual is written for software version 3.00. If you've used a DMXter in the past, you'll find much remains the same; but there are enough changes that you'll save yourself some aggravation by reading at least some of the manual.

USITT DMX512-A AND THIS SOFTWARE

The MiniDMXter4 supports the recommendations, requirements and terminology of ANSI E1.11 aka DMX512-A.

HARDWARE FEATURES OF THE MiniDMXter4

- A micro controller running at 48 mHz
- Four and a half megabytes of non volatile RAM for data storage
- The physical layer supports both DMX512-A and RDM (E1.20).
- A USB interface allows use of a PC as a data terminal for the DMXter. The USB port provides the means for software updates to be entered into flash memory in the field using a file E-mailed to the user.
- The USB port also allows a personal computer to serve as an I/O device for routines run by the MiniDMXter4.

0.0 SAFETY WARNING

Due to failure of either the dimmers or the console, or due to a short between the DMX512 line and power cables, it is possible that a DMX512 control cable may be connected to the AC mains. If connected to the AC mains, a DMX512 cable would be carrying hazardous voltages. If any conductor of a DMX512 cable is connected to the AC mains it is possible that the metal case of the connector is also connected to the AC line. Care should always be taken when testing an installed DMX512 cable that no hazardous potentials are present.

The user should note the following:

Testing of DMX512 lines that are shorted to the AC line is hazardous and should not be attempted.

The MiniDMXter4 does NOT indicate the presence of hazardous voltages on the DMX512 lines.

The metal frame and metal front panel parts of the MiniDMXter4 are not grounded. The impedance between the DMX512 lines entering the MiniDMXter4 and the metal frame is approximately 22 megOhms. The frame should not become 'hot' if there is AC leakage on the DMX512 lines. But do not rely on this for your safety - check that YOUR DMX512 lines are not 'hot'.

0.2 PRECAUTIONS THAT WILL ASSURE THE BEST OPERATION OF YOUR MiniDMXter4

The MiniDMXter4 is a sensitive piece of test equipment designed to receive and decode low power digital signals even when those signals are in an electrically noisy environment. It is also a piece of theatrical field service equipment. We know that field conditions in a theater or studio are often as close to a war zone as most of us wish to get. The MiniDMXter4 is designed to work in this hostile environment.

¹ *Lil'*DMXter, DMXter4 and MiniDMXter4 are trademarks of GODDARD DESIGN CO.

One environmental threat that is always present particularly for a portable piece of equipment is static electricity or ESD. On a dry winter day a person walking across a wool carpet may easily become charged to **8 to 10 thousand volts**. Touch a piece of conductive material and a large pulse of current will flow.

The MiniDMXter4 has been designed to deal with this fact. It's unlikely that normal ESD will damage the unit and if sensible precautions are taken ESD should not prevent it from operating normally.

0.1.1 Use a Blanking Plug in Unused DMX Connectors

When the unit is operating always have a plug in both the DMX OUT and the DMX IN connectors. Since the MiniDMXter is often used with only one cable connection, the other connector should be capped with an un-wired XLR style plug. This plug must be of the metal body type and should be totally un-wired. The purpose of this plug is to prevent ESD discharge to the open connector pins. Such discharge is unlikely to harm the MiniDMXter but it may cause mis-operation, possibly requiring power cycling to reset the unit.

0.2 GETTING STARTED - QUICKLY

So you want to play **NOW**? First read the **SAFETY WARNING** above. Then go right ahead. We feel that the operation of the MiniDMXter4 is fairly straightforward. But we would suggest that you read the following sections before you start taking our name in vain:

1.0 - 1.3 CONVENTIONS (all of it)

2.0 TURNING ON

3.0 MAIN MENU

4.0 TRANSMIT DMX - The most commonly used functions in **TRANSMIT** are:

4.1 ADJUSTING ONE SLOT

4.6 SEND/EDIT SNAPSHOT

5.0 RECEIVE DMX

5.1 VIEW LEVELS

1 CONVENTIONS

As with any software-based device, we have set up some conventions.

1.1 KEY CONVENTIONS

The block of seven keys on the unit is used for most of the operation of the unit.

1.1.1 ACTION ON KEY UP

As a rule the MiniDMXter4 software takes action on key release, not on key press. The exceptions to this rule include auto repeat functions. For brevity this manual will refer to 'press <xx> key' even when action will take place after the key is depressed and released. When we feel it is important, or where confusion is possible, we will lay out the key strokes in detail.

1.1.2 <BLUE>

The **BLUE**> key is the 'YES' answer to queries and initiates the action that you have chosen in most cases. When the MiniDMXter4 is performing functions where a yes/no answer would be inappropriate, there will no longer be a '?' in the display. At this point the <BLUE> key will 'Quit' the work you have been doing and generally put you back to the point in the menu at which you entered. There are some exceptions to this rule; quitting some functions will return you to different points in the menu. These will be pointed out later in the manual.

1.1.3 THE <BACK> KEY

The <BACK> key usually terminates a function, similar to the use of the <BLUE> key. Pressing it when you are in a menu query will back the MiniDMXter4 up one menu layer. Since some of the menus have become rather deep, this can be a real time saver.

1.1.4 <RED>

A few routines in Version 3.00 implement the <RED> or <MORE> key. This is the “now for something completely different” use. An example - in the RDM controller, pressing the <RED> key switches you to a shortcut menu. Any place the <RED> key is used, it will be pointed out in that manual section.

1.1.5 <UP>, <DOWN>

<UP> and <DOWN> are used to step thru items of the menus. When setting slot levels or changing the value of a numeric parameter the MiniDMXter4 uses the <UP> and <DOWN> keys to raise and lower the numeric values.



They also function as the ‘no’ to answer the queries of the menu. Pressing <DOWN> tells the MiniDMXter4 ‘no’ to the current query, and advances you to the next choice. Pressing <UP> tells the MiniDMXter4 ‘no’ to the current query, and backs you up to the previous choice.

1.1.5.1 Bumping a Numeric Value to Minimum or Maximum:

Hold the <BLUE> button down while you press the <UP> key to jump a numeric value to maximum. Hold the <BLUE> button down while you press the <DOWN> key to bump a numeric value to its minimum value. This will work with most, but not all, numeric values that are set by the <UP> and <DOWN> keys.

1.1.5.2 Bumping a Numeric Value to Half:

Press both <DOWN> and <UP> then release both keys. A numeric value will be taken to its half value. This will work with most, but not all, numeric values that are set by the <UP> and <DOWN> keys.

1.1.5.3 Auto-incrementing a Numeric Value:

Many numeric values set with the <UP> and <DOWN> keys may be auto-incremented by holding down the <UP> key. If you hold down the <DOWN> key, the value will auto-decrement towards its minimum.

1.1.6 <LEFT>, <RIGHT>

The most frequent use of the right and left arrows is changing the current slot numbers. In displays that have an underline cursor they are used to move the cursor. While they are marked with arrows, for the remainder of this manual they will be referred to as <LEFT> and <RIGHT>.

1.1.6.1 Changing a Slot Number by One:

To increase a slot number by one press the <RIGHT> key. To decrease a slot number press the <LEFT> key.

1.1.6.2 Auto-increment The Slot Number:

Hold down the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement the slot numbers by one.

1.1.6.3 Jumping the Slot Number by 10:

Hold down the <BLUE> key and press and release the <RIGHT> or <LEFT> key to increment or decrement the slot number by 10.

1.1.6.5 Auto-increment the Slot Number by 10:

Hold down <BLUE> and then press and hold the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement by 10.

1.1.6.6 Forcing the Slot Number to One:

In routines that reference a slot number pressing both <LEFT> and <RIGHT> simultaneously will reset the slot number to one. This key combination is also used to see cue details in ShowSaver.

1.1.7 <UP><RIGHT> Cycles Through Number Formats

The native format of most data in the MiniDMXter4 is 8-bit binary. Eight bit binary is seldom the best way to display data. The MiniDMXter4 can display 8-bit slot values in three formats; percent, decimal or hexadecimal. You can select the default number format in the Setup Menu. Pressing the <UP> and the <RIGHT> keys at the same time will cause the unit to cycle through the three number formats. Details on the display formats can be found in [section 1.3](#).

1.1.8 <BLUE> As a Shift Key

There are several places in this software that use <BLUE> as a shift key to allow one of the other keys to access a second function or status display. When accessing a second function the <BLUE> is pressed and held while the second key is pressed and released.

1.2 DISPLAY CONVENTIONS

There are two different purposes of the display. One is to allow you to move around the menu structure to the area you need for the test you want to perform. Here the top line of the display will generally tell you where you are in the menu, and the second line will usually ask you a question or give you a choice of actions. These displays are always in the form of a question and will contain a '?'.
The other purpose of the display is to give you information about the DMX512 system you are testing. This will be done either in one line or two line messages.

1.3 NUMBER CONVENTIONS

DMX512 uses an 8-bit binary byte to transmit slot levels and the START Code. This allows 256 different slot levels and START Codes from 0 to 255. Most lighting consoles display these levels as 0 to 100. This means that a console with a slot set to 50 does not transmit the number 50 on the DMX512 line, but a number that is 50% of 255, i.e., 128. The normal lighting console 0 to 100 representation of slot levels is really a percent scale and will be referred to as 'percent' throughout this manual. Details of the percent conversion used by the MiniDMXter4 can be found in section 20.7

The MiniDMXter4 can display numbers in three formats: decimal, percent, or hexadecimal. Decimal, percent, or hexadecimal notations are available for levels. Decimal or hexadecimal notations are available for the START Code, and for the **FLICKER FINDER** compare limit. When the MiniDMXter4 is set to percent mode, the START Code and the **FLICKER FINDER** compare limit will be displayed in decimal. Slot numbers and timing information are available in decimal notation only. The status may be changed by queries in the **SETUP OPTIONS** menu (see section 8.4).

1.3.1 Default Display Format

The default format is percent for any value that is displayable in percent. Any readout displayed in hex will be two hex digits ending with a lower-case 'h'. Any readout displayed in percent will contain a % sign in the display.

2 TURNING THE UNIT OFF AND ON

An on/off switch is on the top of the unit. Turning the unit on will display this screen:

```
| MiniDMXter4 3.00 |  
| Goddard Design Co. |
```

This message includes the software version. This manual is written for software Version V3.00. It is applicable for any software version that is less than V3.10. This message will last for about three seconds or until any one of the keys in the cross is pressed and released. The second line of this display indicates which optional software is in the unit.

```
| MiniDMXter4 3.00 |  
| with ShowSaver |
```

This message also lasts for about three seconds or until any one of the keys in the cross is pressed and released.

2.1 IF THE UNIT WILL NOT TURN ON . . .

If the unit will not turn on, but instead displays

```
| MiniDMXter4 3.00 |  
| MEAL PENALTY |
```

Then the battery has discharged to the point that it is not capable of supporting normal operation. Feed it new batteries or plug it into an external power source.

2.2 RESETTING TO FACTORY DEFAULTS

The MiniDMXter4's software has a number of settable parameters or variables. The Transmit routine in particular is 'table driven'. These tables are stored in memory. It is possible to set some user settable parameters to rather unusual settings. It is also possible that certain parameters may be corrupted. Some parameters are reset every time the unit is turned on. However, parameters that we feel the user may wish to keep from session to session are stored in non-volatile memory.

To reset the parameters to factory default:

Press and **hold** the <BLUE> while turning the unit on. All internal parameters are now reset to the factory default values. This is confirmed by the following message: |Cold Boot/MemCleared|

If you updated your software, the routine to reset the defaults will run automatically and you will see the above message as you turn the unit on.

2.3 OWNER IDENTIFICATION MESSAGE (OPTIONAL)

We offer an optional internal identification message that briefly displays:

```
| PROPERTY OF |  
| LITES'R'US |
```

Or any two lines of 20 alphanumeric characters. If you have ordered this option, the message will last three seconds. This message may be keyed through in the same way that the version numbers can be keyed through. If your unit is not fitted with this option, this message will not be seen. This option must be entered at the factory. It is not field programable.

2.4 THE DISPLAY BACKLITE

The backlite will time out if you haven't used the keys in about one minute. To turn it back on, press any key.

3 MAIN MENU

The MiniDMXter4 works on a function menu. All tests and functions of the MiniDMXter4 are accessed by way of seven MAIN MENUs. You can step thru the choices by pressing the <UP> or <DOWN> keys until you come to the function you wish to use. To select that function, press <BLUE>. The functions are:

| | |
|------------------|----------------------------|
| TRANSMIT DMX512? | Section 4 |
| RECEIVE DMX512? | Section 5 |
| CABLE TESTER? | Section 7 |
| SETUP OPTIONS? | Section 8 |
| FLICKER FINDER? | Section 9 |
| SHOW SAVER? | Section 12 |
| RDM CONTROLLER? | Section 15 |

4 TRANSMIT DMX

TRANSMIT DMX is one of the primary diagnostic tools offered by the MiniDMXter4 . The unit can transmit a DMX512 signal to allow you to check that the receive end of your transmission link is correctly receiving the signal.

Originally DMX512 was a standard primarily intended to communicate level information to dimmers. It had provisions for non-level or non-dimmer communications by means of a 'START Code'. For dimmer communication the START Code has a value of 0, sometimes referred to as the 'null START Code'. The default START Code setting in the MiniDMXter4 is therefore 0.

4.0.1 If a Non-zero START Code Is Set

If you previously changed the START Code to a non-0 value, you will now be informed of this fact and given the chance to change the START Code if you wish. If you do not wish to change the START Code, press <DOWN>. Pressing <UP> will return you to the MAIN MENU.

4.0.2 If a Non-standard 'Flavor' Is Set

The MiniDMXter4 provides considerable control of the parameters of the transmitted DMX signal. This is required because DMX512 allows many parameters to vary over wide ranges. Our method of allowing you to select groups of preset parameters is called selecting the 'flavor'. See the discussion of flavors in Section 4.7 below. The MiniDMXter4 's default 'flavor' setting is a flavor using conservative times, producing a 10Hz update rate. This is the default specifically because it conserves the battery. Details of the available 7 flavors are shown in Table Xx following.

If you previously changed the 'flavor' to one other than Mini Standard 10Hz, you will now be informed of this fact and given the chance to change it if you wish.

4.1 ADJUSTING ONE SLOT

If you want to look at the output of one dimmer, or if you want to use the MiniDMXter4 as a focusing remote, you want to use the first choice in the **TRANSMIT DMX512** menu.

```
| TRANSMIT DMX512 |  
| ADJUST ONE SLOT? |
```

If you choose <BLUE>, you will get a new display reading

```
| SENDING SLOT 1 |  
| TO LEVEL 0% |
```

The level may be displayed in decimal, percent or hex. This status may be changed by queries in the SETUP OPTIONS menu (see section 8.4). If percent is used, the level is followed by a % sign. If hex is used, the display will show two hex digits followed by a lower-case 'h'. Change the slot number by using the <RIGHT> and <LEFT> keys; with the default 'flavor' setting you may choose slots from 1 to 512. The methods of changing the slot number are summarized in the side bar on this page.

Use the <UP> and <DOWN> keys to change the level. The methods of changing the level are summarized in the side bar on this page.

4.2 REENTERING ADJUST ONE

If you press <BLUE> to exit this routine and then press it again to re-enter, you will return pointing to the last slot that you were editing. If you exit to the MAIN MENU you will reset the slot to one. Taking or erasing the snapshot will also reset the slot number to one. This behavior is uniform for all routines that use a slot number.

4.3 AUTOFADING ONE SLOT

This menu item is a test that allows you to cycle slots up and down automatically. It has two modes; one cycles one slot continuously, the other cycles a slot once and then steps to the next slot. You may choose whether a slot cycles from off to full and back to off (fade UP) or cycles from full to off and returns to full (fade DOWN).

If you answer <BLUE> to this question you will cause the MiniDMXter4 to cycle a slot once and then step to the next slot. If you answer <DOWN> to this question the MiniDMXter4 will cycle the same slot up and down continually.

The display will be static. The MiniDMXter4 will have started to transmit. The level sent will be an unchanging zero. To start the auto fade press either <UP> or <DOWN>. Pressing <UP> causes the MiniDMXter4 to start fading from zero up to full and then back to zero. Pressing <DOWN> causes the unit to start fading with the slot set to full, fade the slot to zero and then back up to full. If you **ENABLE AUTOSTEP** and select <UP>, slot 1 will fade to full and then back to zero. When it reaches zero the slot number will increment to slot 2 and the level will start fading from zero to full. If you **ENABLE AUTOSTEP** and select <DOWN> slot 1 will bump to full, fade to zero and then back to full. When it reaches full it will bump to zero, the slot number will increment to slot 2, slot 2 will bump to full and start fading from full to zero. In either case the MiniDMXter4 will cycle through all the slots.

The <LEFT> and <RIGHT> keys operate in the same way as in **ADJUSTING ONE SLOT** above and may be used to change which slots are autofaded. If you did not **ENABLE AUTOSTEP** you must use the <LEFT> or <RIGHT> key to select the slot to autofade. Pressing <LEFT> or <RIGHT> zeros the old slot and sets the new slot to the beginning of its fade, either full or zero depending on whether we are fading <UP> or <DOWN>.

You may temporarily stop the fade by pressing <BLUE> and either <UP> or <DOWN>. Pressing <UP> forces the slot to full; pressing <DOWN> forces the slot to zero. With the fade stopped, pressing either <UP> or <DOWN> will restart the fade.

The level may be displayed in decimal, percent or hex. The current status may be changed by queries in the SETUP OPTIONS menu (see section 8.4). If percent is used the level is followed by a % sign. If hex is used, the display will show two hex digits followed by a lower-case 'h'. This is one menu from which you cannot change the number format.

4.4 CLEARING THE SNAPSHOT

The MiniDMXter4 can 'take a snapshot' of slot level information transmitted down the line, assuming you have plugged the input of the MiniDMXter4 into the line coming from a working console. This is a useful function that we will discuss later. You may also build a snapshot slot by slot, using the MiniDMXter4 's keys. Before doing this you may wish to clear the old snapshot.

The MiniDMXter4 will ask you

```
TRANSMIT DMX512
CLEAR SNAPSHOT?
```

you should press <BLUE> to answer yes. The unit will next ask

```
CLEAR SNAPSHOT?
ARE YOU SURE?
```

This gives you a second chance if you didn't really mean to clear it. If you did, press <BLUE> again and the unit will momentarily read

```
ZZAAPP!!  
SNAPSHOT IS HISTORY!
```

The MiniDMXter4 will then drop thru to:

```
TRANSMIT DMX512  
SEND/EDIT SNAPSHOT?
```

skipping the TAKE NEW SNAPSHOT menu item.

4.5 TAKING NEW SNAPSHOT

The MiniDMXter4 can take the information it receives from the digital line and hold it in memory for later use. Taking a snapshot overwrites any old snapshot.

When you press <BLUE> the top line of the display will briefly read TAKING SNAPSHOT. Assuming that there is data to be recorded, the bottom line will read briefly SNAPSHOT RECORDED. After a brief pause, the MiniDMXter4 will drop thru to the next menu entry and the display will read

```
TRANSMIT DMX512  
SEND/EDIT SNAPSHOT?
```

The snapshot function is START Code sensitive. If your MiniDMXter4 is still reading TAKING SNAPSHOT for more than three seconds, and the bottom line remains blank, this means that your unit is receiving data with a different START Code than the one it is currently set to receive.

After 3 seconds, if no digital input is received, or if the input is not a digital form that the MiniDMXter4 can recognize, you will see

```
NO DIGITAL INPUT  
OR INPUT NOT DMX512
```

When you see this message on the display, first check to see that you have a cable plugged into the MiniDMXter4 input connector and into the output connector of a working console.

Many menu items erase a snapshot.

4.5.1 Actions That Overwrite or Erase a Snapshot

The following events will overwrite a snapshot with a new snapshot:

- 1 - Taking a new snapshot
- 2 - Using the **FLICKER FINDER**
- 3 - Using **VIEW LEVELS**. Whatever levels are in the table at the time one exits **VIEW LEVELS** will be preserved and may be used as a snapshot.
- 4 - **SHOW SAVER: RECORD SCENE, EDIT SCENE, and PLAYBACK SCENE**

The following events will erase a snapshot and leave the table clear:

- 1 - **ADJUST ONE SLOT**
- 2 - **ADJUST ALL SLOTS**
- 3 - Using **CLEAR SNAPSHOT**
- 4 - Shutting down due to low battery (showing you **MEAL PENALTY**)

4.6 SEND/EDIT SNAPSHOT

Pressing the <BLUE> key will start sending the entire snapshot to the dimmers and will display levels of four slots at a time. You can edit this as you need: use the <RIGHT> and <LEFT> keys for changing the slot numbers. Use the <UP> and <DOWN> keys for changing the level of the slot displayed in the left-most position on the display.

The levels may be displayed in decimal, percent or hex. If percent is used `LEV:` is changed to read `LEV%`. If hex is used, the display will show two hex digits followed by a lower-case 'h'.

Slot number and slot level may be set using the key presses summarized in the side bar on page 10

4.6.1 Searching for the next Slot with Level

Press and hold the `<DOWN>` key while pressing and releasing `<RIGHT>` or `<LEFT>` keys to search for next higher (`<RIGHT>`) or lower (`<LEFT>`) slot with a level. The next slot with a level greater or equal to the search minimum will be displayed in the leftmost position of the display

4.6.2 Re-entering Send/Edit Snapshot

On exiting **SEND/EDIT SNAPSHOT** the transmitter is turned off, but the current slot number is NOT reset. Therefore you may simply press `<BLUE>` again and restart exactly where you left off. This means that a finger stutter on the keys is not a disaster. You may also pause during a focus session and return to where you were.

If you exit to the MAIN MENU you will reset the slot number to slot one. Taking or erasing the snapshot will also reset the slot number to one. This behavior is uniform for all routines that use a slot number.

4.6.3 Clearing the Snapshot Within Send/Edit

You can set all slot levels to zero from within **SEND/EDIT SNAPSHOT**. Hold the `<BLUE>` and `<DOWN>` keys. After about 3 seconds the display will change to read:

```
| SLT:  25  26  27  28 |  
|  CLEAR SNAPSHOT?    |
```

The top line of the display will not change; only the bottom line is rewritten. Release both keys. Now pressing `<BLUE>` will clear all the slots, pressing `<UP>` or `<DOWN>` will return you to **SEND/EDIT SNAPSHOT**.

4.7 SEND FLAVOR

Although they are 'standards', there are many parameters of DMX512-A that are permitted to vary over a wide range. These parameters may vary from product to product or even from moment to moment at the output of the same product. The Standard defines the acceptable range within which a number of parameters of the transmitted signal are permitted to vary. The MiniDMXter4 allows you to vary 5 important parameters of the DMX512 signal. Three of these parameters may be adjusted to values that fall outside those permitted by the Standards. We provide these out-of-Standard test signals to allow sophisticated testing of DMX receivers. It should be understood that one piece of equipment's ability to operate outside the Standard does not make it inherently a 'better' piece of gear than one that does not!

We have provided a selection of parameter groupings which we call flavors. Choosing a flavor refers to choosing a preset of parameters for the transmitted signal. The concept of flavors applies only to a transmitted signal generated by the MiniDMXter4 and not to reception.

| There are 8 Preset 'flavor' choices : | | | | | | |
|---------------------------------------|-------|------|-------|------|------|-------------|
| NAME | BREAK | MAB | SLOTS | IST | MBB | Updates/Sec |
| Mini STANDARD 10Hz | 100μs | 20μs | 512 | 21μs | 59ms | 10 |
| E1.11 (DMX512-A) | 92μs | 12μs | 512 | 0μs | 4μs | 44.08 |
| DMX512/1990 8μs MAB | 88μs | 8μs | 512 | 0μs | 4μs | 44.1 |
| 24 SLOTS 8μs MAB | 88μs | 8μs | 24 | 0μs | 4μs | 830.6 |
| DMX512/1990 4μs MAB | 88μs | 4μs | 512 | 0μs | 4μs | 44.1 |
| 24 SLOTS 4us MAB | 88μs | 4μs | 24 | 0μs | 4μs | 833.3 |
| 70μs BK 4μs MAB 20 S | 70μs | 4μs | 20 | 0μs | 4μs | 966 |
| Colortran Option | 215μs | 21μs | 512 | 2μ | 4μs | 26 |

Table 4-1

BREAK = BREAK TIME
MAB = MARK AFTER BREAK
SLOTS = NUMBER OF SLOTS
IST = INTERSLOT TIME
MBB = MARK BEFORE BREAK

Getting into the **SEND FLAVOR** submenu will put you at the last flavor that was set. You may step thru the choices from there. Use the <BLUE> key to select your flavor and return to the **TRANSMIT** submenu. You will find yourself at the **ADJUST ONE SLOT** choice. This is an exception to the general rule that <BLUE> returns you to the point from which you entered the menu.

4.8 BACK TO MAIN MENU

4.9 CHANGING THE START CODE

DMX512 is a standard primarily intended to communicate level information to dimmers. It has provisions for non-level or non-dimmer communications by means of a 'START Code'. For dimmer communication the start code has a value of 0, sometimes referred to as the 'null start code'. The default START Code setting in the MiniDMXter4 is therefore 0. Some of this equipment uses non-0 START Codes. The MiniDMXter4 provides you with the ability to set the START Code you need for the type of equipment you are testing.

If you press <BLUE> the display will read

```
START CODE IS  0
CHANGE START CODE
```

Press the <UP> and <DOWN> keys to change the start code to your desired setting. Pressing <UP> and <DOWN> together will cause the start code to bump to 128. Pressing <BLUE> and <DOWN> together will return the start code to zero. When the desired value is displayed, press the <BLUE> key to save this value. The MiniDMXter4 will use this value as its START Code for both standard **TRANSMIT** and **RECEIVE** until it is changed again by the user.

The following routines use special alternate START Codes and are not affected by the setting of this menu item.

| Table 4-2 | HEX | DEC |
|-------------------------|-----|-----|
| The Hex 55 test message | 55h | 85 |
| Text messages | 17h | 23 |

| | | |
|---------------------------|-----|-----|
| RDM request and responses | CCH | 204 |
|---------------------------|-----|-----|

The START Code initializes to 0 when the factory defaults have been restored. See section 2.5 & **MEAL PENALTY** Section 19.3 The START Code may be displayed in hex. The current status may be changed by queries in the SETUP OPTIONS menu (see section 8.4) or by using <UP> <RIGHT>. START Codes may only be displayed in decimal or hex. If percent is selected for levels via SETUP OPTIONS START Codes will be displayed in decimal.

Exiting **CHANGE START Code** jumps you to **ADJUST ONE SLOT**.

This is an exception to the general rule that <BLUE> returns you to the point at which you entered the menu.

4.9.1 MAB Accuracy Vs. START Code

If the START Code is set to 0 and the break length is less than 16mS, the mark after break should be essentially jitter-free. When you set a non-0 START Code or when the break time is longer than 16mS, regardless of START Code, we change the method of generating the mark after break. This alternate method has an uncertainty of 4µs. The MAB will be the length set by the current flavor or up to 4 µs longer.

4.10 SETTING THE MINIMUM LEVEL FOR SEARCHES

In **SEND /EDIT** pressing and holding down the <DOWN> key and then pressing either <LEFT> or <RIGHT> will cause it to search the slot table for the next higher or lower slot with a level greater or equal to the search minimum.

4.11 ADVANCED TRANSMIT ROUTINES

This menu item is the entry point to a submenu. In the present version of the software this menu has five diagnostic routines which make use of new features of DMX512-A . In earlier MiniDMXter4s, the Adjust All Slots routine was found elsewhere.

4.11.1 Adjust All Slots

This function allows you to set all the slots to the same level at once. Use the <UP> and <DOWN> keys. If you hold down the <UP> key, the slot levels will auto-increment towards full. If you hold down the <DOWN> key, the slot levels will auto-decrement towards zero.

The level may be displayed in decimal, percent or hex. The current status may be changed by pressing <RIGHT> <UP> simultaneously. It can also be changed by a query in the SETUP OPTIONS menu (see section 8.4).

Note the default settings will not allow you to bring all the slots to half or full at once. Many installations lack the power service to handle everything at full at once, and we don't own a piece of any fuse or circuit breaker manufacturer. Note even a location that could handle the load of all slots at full may not handle the surge caused by cold lamps.

In this software there is a switch to enable bumping all slots. (See section 8.6) When enabled you may bump all slots to full, half and of course zero. Be careful when you use this feature. Blowing the service may be momentarily exciting, but... we don't have to fix it and you do.

4.11.2 DMX512 TEST PACKET - HEX

55 This item sends a packet with the START Code set to hex 55 followed by 512 slots of hex 55.

Viewing the Text Packet- Moving about the Display

AUTO-INCREMENT: Hold down the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement the character position by one.

JUMP BY 10: Hold down the <BLUE> key and press the <RIGHT> or <LEFT> key to increment or decrement the character position by 10.

AUTO-INCREMENT BY 10: Hold down <BLUE> and then press and hold the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement by 10.

RETURNING TO THE FIRST CHARACTER: Press both the <RIGHT> and <LEFT> keys to return to the first character which is in slot 3.

These packets have every other bit set. It was included in the new version of DMX512 as a test pattern. It may be useful for measuring bit delay and bit distortion through DMX512 repeaters and splitters. While it will seldom be used in day to day testing of a working lighting system, when the bits hit the fan it can be very useful.

4.11.3 Sending Text Packets

Another new feature of DMX512-A is the TEXT PACKET. Today there are many DMX512 transmitters that are not large lighting consoles. Many devices designed for embedded applications require very little user interface *once they are configured*. However configuring or troubleshooting these devices is difficult at best. The present software provides two routines supporting Text Packet; this routine and a Text Packet Receiving routine in the Receive Menu. Both routines use the same user interface. This routine is intended to test other Text Packet receiving devices. The Text Packet Receive routine can be used to monitor DMX512-A devices that support this feature.

```
|MS# 0 L- 24 C- 3|
|miniDMXter4 v3.01█|
```

The display above is what you will see on entry to this routine. The MiniDMXter4 can send several different stored text messages. This release has eight different messages. They have been chosen to test the compatibility of a displaying device with this feature. Details on required packet format and the currently supported messages are in Appendix A

You may change which packet you are sending by using the <UP> and <DOWN> keys. You can scroll through a message using the <LEFT> and <RIGHT> keys.

Technical note:

Text Messages are sent with a special START Code 17h and generally will not be viewable by Null START Code receiving devices. More technical details are in Appendix A

MS# DMX512-A allows for a device to send up to 256 different text messages. They are numbered from 0 to 255. This routine generates up to 8 canned text messages. The above screen is the first canned message in the MiniDMXter4

L- Text message packets may have from 24 to 512 data slots, plus the START Code. (See the Appendix A This field shows the length of the packet that is currently being transmitted.

C- This is the position within the packet of the character that is in the first display position on the second line of the display. As you use the <LEFT> and <RIGHT> keys to move about the display this number lets you know where you are.

5 RECEIVE DMX512

Answering <BLUE> to the RECEIVE DMX512? query puts you in the **RECEIVE** menu, the first question the user needs to answer is

```
| RECEIVE DMX512 |
| AT END OF LINE? |
```

DMX512 systems may be wired as a 'daisy chain' with multiple receivers connected in series by a cable going from the console to receiver 1, another cable going from receiver 1 to receiver 2, and then on from there until all the receivers are connected in a chain. The last receiver in the chain is required to terminate the line. For more information on termination, please see Section 20.6.3.

The MiniDMXter4 always terminates the line. This a major difference between it and its big brother, the DMXter4 RDM. However, the MiniDMXter4 may be inserted at any point in the daisy chain. That is because its transmitter circuit can be switched on to forward an identical DMX512 data stream. Answering 'No' to the 'at end of line?' question switches on the transmitter for all receive menus.

If you do not need to drive additional devices down stream of the Mini answer '<YES>' to this question.

Turning on the transmitter increase current consumption and decreases battery operating time.

5.0.1 If a Non-zero START Code Is Set

If you previously changed the START Code to a non-0 value, you will be informed of this fact and given the chance to change the START Code if you wish.

5.1 VIEW LEVELS

Pressing the <BLUE> key will display 4 slot numbers on the top line and their levels below. The unit allows you to step thru the levels for all of the slots displaying 4 at one time.

Regardless of how many slots are being transmitted, there will always be 512 entries in the slot table. The level value for slots that are not being transmitted will be displayed as 0. If you wish to know how many slots are being transmitted, see **5.1.4 RECEIVED SLOT SUMMARY DISPLAY** below.

The levels may be displayed in decimal, percent or hex. The current status may be changed by queries in the SETUP OPTIONS menu (see section 8.4). If percent is used LEV: is changed to read LEV%. If hex is used, the display will show two hex digits followed by a lower-case 'h'.

If you wish to change the display format immediately, use the short cut keys shown in the side bar to the left of this text.

5.1.1 Display and Timeout Rules

When the Lil'DMXter was first built, very few devices made regular use of Alternate START Code packets. While most DMX is still Null START Code packets, ASC packets are seen far more often than in the past. In the past if you saw data on the screen it was likely that was the only data on the link. If the null packets stopped coming you would soon see a no data message.

If you are dealing with a DMX512 system that mixes Null and ASC packets it is helpful to understand the display and timeout rules.

If after 3 seconds the MiniDMXter4 does not receive DMX512 data on **any START Code**, the display will change to

```
NO DIGITAL INPUT
OR INPUT NOT DMX512
```

When this message is displayed reception of DMX512 stops. However the buffer is not cleared. Whatever was last received is still in the buffer. This is a latched display. After correcting the problem you may clear the NO DIGITAL INPUT display by restarting the **VIEW LEVELS** section. This is done either by using the <UP> or <DOWN> keys.

If a system that mixes Null and ASC messages stops updating the Null packets but continues to send ASC packets the 'no data message' will NOT appear. As long as some valid DMX512 packet is received every 3 seconds no time out occurs. Simply viewing the display would not indicate this.

5.1.2 <UP> Clears the Display Buffer and Restarts Receive

QUICK STEPPING THRU SLOTS AND LEVELS

Slot - AUTO-INCREMENT: Hold down the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement the slot numbers by one.

Slot - JUMP BY 10: Hold down the <BLUE> key and press the <RIGHT> or <LEFT> key to increment or decrement the slot number by 10.

Slot - AUTO-INCREMENT BY 10: Hold down <BLUE> and then press and hold the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement by 10.

RETURN TO Slot ONE: Press both the <RIGHT> and <LEFT> keys to return the slot number to one.

FORMAT - CYCLING THRU FORMATS: Pressing both <UP> and <RIGHT> cycles thru the three number formats

Pressing <UP> will restart the receive routine and will clear the receive buffer. When the key is released the bottom line of the display will momentarily display the word 'CLEAR'. The <UP> key can be used at any time to see if the display is being updated or is static.

5.1.3 <DOWN> Restarts the Receiver

Pressing <DOWN> restarts the receive routine and will show you the data that was in the buffer at the time the time out occurred. When the key is released the word 'RESTARTING' momentarily appears on the bottom line.

5.1.4 Received Slot Summary Display

Hold down the <BLUE> key and press <DOWN>. You will see the following display

```
23 OF 256 L >= 1%
SLT: 2 TO SLT 100
```

The top line of this display tells you the total number of slots received, in the case above, 256, and the number of slots having a level greater or equal to the search minimum. In this case, 23 slots have a level greater than or equal to 1 percent.. The bottom line lists the lowest slot and the highest slot to have a level greater than or equal to the search minimum. The search minimum can be set from 0 to 255; it is set by its own menu item (see Section 5.6)

5.1.5 Data Error While Viewing Levels


If a significant data transmission error is detected, the first three characters of the second line of the display will read ERR instead of LEV. You may view the error and clear the ERR flag by pressing and holding <BLUE> and then pressing <UP>. The display will be the same as the first display in VIEW PARAMETERS.

5.2 VIEW LEVEL GRAPHICALLY

This routine allows 32 slots to be viewed at once for a quick overview. The number at the beginning of the top line is the starting slot number for that line. The



remaining 16 character cells display a graphic representation for 16 consecutive slots. Sixteen more slot values are displayed on the bottom line. Each slot is displayed as a 10-state bar graph. One




state shows which slots are at zero, one state shows which slots are at full. The remaining 8 states show intermediate levels. A blank character cell is a zero. A fully

filled character cell is a value of 255 (hex FF). The remaining levels are shown as a variable height goal post.

The graphic to the right shows the ten steps in the first 10 slots. The break points are as listed in the table below.

Pressing <UP> and <DOWN> at the same time will change the display so that the bottom line displays the numeric value of the first displayed slot on the top line.



| | | | | | | | | | |
|---|----|----|----|-----|-----|-----|-----|-----|-----|
| 0 | 01 | 32 | 64 | 96 | 128 | 160 | 192 | 224 | 255 |
| | 31 | 63 | 95 | 127 | 159 | 191 | 223 | 254 | |

Graphic mode break points

5.3 VIEW ON USB TERMINAL

If you have a PC with a terminal emulator installed you can now view the DMX levels on your PC. Information on setting up the terminal emulator is in this manual in section 22. More detailed information is on our web site at,

www.goddarddesign.com/usb2.html.

It is best to connect the USB connection and launch the emulator before entering this menu. If you don't you will be told to do so. The display on the PC should look like the one shown below except it will have seven pairs of lines with slot levels data. The entry display will show slots 1 through 128. Three other pages are

available to show all 512 slots. The display below is a percent display, decimal and hex displays are also supported.

```

DMXter 4 RDM   View Levels Page 1 (1-128)
PROTOCOL:DMX%   Receiving Data

  1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20
100 50 100 50 50  50  50  50  50  50  50  50  50  50  50  50  50  50

```

To see the other 3 pages of slot values use the <LEFT> or <RIGHT> keys. The following key presses are also available and work the same way the do in VIEW LEVELS:

```

<UP><RIGHT>   Selects the number format.
<UP>          Clears the receive buffer and restarts reception
<BLUE><UP>    Shows the error summary display
<DOWN>       Restarts reception
<BLUE><DOWN>  Shows the slot range summary

```

5.4 VIEW PARAMETERS

Whenever the MiniDMXter4 is receiving DMX512 it checks for the following problems:

```

PE = PARITY ERROR
FE = FRAMING ERROR
BK = BREAK TOO SHORT (less than 88µs)
MK = MARK AFTER BREAK TOO SHORT (less than 8µs)
DMX512/1986 called for a 4µs mark. DMX512/1990 requires a mark of 8µs or longer. We flag
marks of less than 8µs as a warning of possible compatibility problems.
OVFL = OVERFLOW (meaning that you have attempted to receive more than 512 slots)
BNW = BROKEN WIRE (The probable cause is Pin 2 or 3 of your cable is open. If this reads as B?W it
means that this feature is disabled. Turn it on again thru the USER SETUP OPTION.

```

If any portion of this test returns an error the unit will show it. An error is shown by an * on the display under the error's code. The display on the left shows two errors, a short break and packet containing more than 512 slots. The display on the right is the 'no error display.

```

| PE FE BK MK OVFL BNW |           | PE FE BK MK OVFL BNW |
|           *           * |           | NO ERRORS DETECTED |

```

Technical Note: We report a **PARITY ERROR** for any frame (byte) that does not have its first stop bit. DMX512 is a no-parity system and the 9th bit should always be high. To prevent false trips on the **BREAK TOO SHORT** and **MARK AFTER BREAK TOO SHORT** measurements, the trip point for these measurements is set as follows: a break must be measured as 87.5µs or less. A mark after break must be measured as 7.5µs or less.

The MiniDMXter4 allows the user to look at certain parameters of the received signal in detail. Pressing the <UP> and <DOWN> keys will scroll the user thru the choices. Pressing <DOWN> will bring you to:

5.4.1 Break Length

BREAK LENGTH reads out a minimum value, a maximum value and an average of the last 32 packets, all expressed in µs(or if appropriate, in milliseconds). The average value will take a few seconds to appear on the display. The MiniDMXter4 can measure the minimum, maximum and average break length for breaks longer than 65µs. If it receives a minimum break time of less than 65µs, the minimum and maximum values will be replaced with the words **TOO SHORT**. This is to warn you that you have exceeded the measurement capability of the MiniDMXter4. The average value will still be shown but its validity should not be counted on. Break length is not START Code sensitive; the break length of all packets is measured regardless of the START Code that the packet is transmitted with.

5.4.2 Mark after Break Length

MARK AFTER BREAK LENGTH reads out a minimum value, a maximum value and an average value for Mark After Break length expressed in μs (or if appropriate, in milliseconds). The average value will take a few seconds to appear on the display. If it receives a minimum mark time of less than $3\mu\text{s}$, the minimum and maximum values will be replaced with the words `TOO SHORT`. This is to warn you that you have exceeded the measurement capability of the MiniDMXter4. The average value will still be shown but its validity should not be counted on. MAB length is not START Code sensitive; the MAB length of all packets is measured regardless of the START Code that the packet is transmitted with.

5.4.3 List Received START Codes

The MiniDMXter4 shows you which START Codes are being sent. It also reminds you which START Code it is currently set to receive levels from. The top line of the display will read

```
START CODES  SET=  X  (where X=the current START Code)
```

The bottom line will read out the START Codes that have been received since the test was started. They will be sorted in numerical order with the lowest number to the left. If more than four START Codes are being received, you will see

```
<  0  4  58  200 > (or something similar)
```

The brackets indicate that you may scroll **<RIGHT>** or **<LEFT>** thru all the START Codes being received.

The START Code may be displayed in hex. The status may be changed by queries in the `SETUP OPTIONS` menu (see section 8.4). START Codes may only be displayed in decimal or hex. If percent is selected for levels via `SETUP OPTIONS` START Codes will be displayed in decimal. If hex is used, the display will show two hex digits followed by a lower-case 'h'.

5.4.4 # of Slots per Packet

This screen reads out the minimum and maximum number of slots per packet. The START Code is not included in this count.

Warning: while the Standard does not require that the number of frames be fixed for all transmissions, if the minimum and maximum number of frames are different, you should suspect a problem. Also you should never receive more than 512 frames. This test is start code sensitive; this test reports the frame count of only those packets transmitted with the currently selected start code.

5.4.5 Interslot Time in μs

This routine measures any extra time between slots. Note that from a users point of view there is no ideal number for this parameter. However, too long a time will decrease the update rate. If you are working with compliant legacy equipment that may not be fully compatible with the standard it can be very useful to have some space between slots. We have added this and the next two routines to provide full development and diagnostic tools.

The display is similar to the Break and the MAB routines. It displays the minimum, average, and maximum time seen. The averaging algorithm for this and the next three routines differs from the one for the other older routines. The reason for this is the time intensive nature of these measurements.

5.4.6 MARK BEFORE BREAK in μs

The time between the end of the last slot of a packet and the break is given several different names, including Inter-Packet Time and Mark Before Break (MBB). Prior to V2.45 for the Lil'DMXter this was not a measured parameter.

5.4.7 MARK AFTER START CODE in μs

The Mark After Start Code is conceptually the same as inter slot time. However some software designs could cause its value to be completely different from Inter-slot time. For that reason we measure it as a separate parameter.

5.4.8 Average Routines for 5.4.5 - 5.4.6 - 5.4.7

The average routines for Break, MAB and Break to Break keep a running average of the last 32 values. This function adds values to a counter, and displays that result when enough data points have been collected. One result of this is that if a parameter is changing the user will not see it count up or down smoothly. It will instead update every second or so with the new average value.

One display note. The measurement method causes the minimum and maximum to have a few micro seconds of jitter. (On the order of 3 micro-seconds) Since zero is an allowable time for these measurement it is possible that a negative time could be returned. We do not display negative times, however we can display a value of '-0'. A value of negative zero means that jitter return a negative result.

5.4.9 Break-to-break Time

This screen reads out the minimum value, the maximum value and an average value. The MiniDMXter4 can measure the minimum, maximum and average break-to-break length of a DMX512 signal where this time is 900µs or longer. If it receives a break-to-break time of less than 900µs, all three values will be removed from the display and be replaced by the words TIME LESS THAN 900µS. Break-to-break time is not START Code sensitive; the break-to-break time of all packets is measured regardless of the START Code that the packet is transmitted with.

The method of measuring break-to-break length on the MiniDMXter4 has a statistical uncertainty of at most +/- 1µs. Added to this uncertainty is any inaccuracy caused by the finite accuracy of the MiniDMXter4's time base. The time base should be accurate to +/-75 parts per million for units.

5.4.10 Updates per Second

This screen reads out the minimum, maximum and average number of DMX512 packets per second. The minimum and the maximum values are refreshed once per second. Thirty-five seconds is required for the average to appear initially. Following that, it is refreshed once per second. To leave this display, press either <UP> or <DOWN> or <BLUE> and hold them for approximately one second. You will know that you have held the key long enough when the numbers on the bottom line of the display have been erased. This test is not START Code sensitive.

5.5 RETURN TO MAIN MENU

5.6 CHANGING THE START CODE

DMX512 is a standard primarily intended to send level information to dimmers. It has provisions for non-level or non-dimmer communications by means of a 'START Code'. For dimmer communication the START Code has a value of 0, referred to as the 'null START Code'. The default START Code setting in the MiniDMXter4 is therefore 0. Some equipment uses non-0 START Codes. The MiniDMXter4 provides you with the ability to set the START Code you need for the type of equipment you are testing.

The display will read

```
| START CODE IS 0 |  
| CHANGE IT? |
```

If you press <BLUE> the display will read

```
| START CODE IS 0 |  
| CHANGE START CODE |
```

Press the <UP> and <DOWN> keys to change the START Code to your desired setting. Pressing <UP> and <DOWN> together will cause the START Code to bump to 128. Pressing <BLUE> and <DOWN> together will return the START Code to zero. When the desired value is displayed, press the <BLUE> key to save this value. The unit will use this value as its START Code for both transmit and receive until it is changed again by the user. When the factory default values have been restored, the unit reinitializes the START Code to 0. See Section 2.5.

The START Code may be displayed in hex. The status may be changed by queries in the SETUP OPTIONS menu (see section 8.4) or by using the <RIGHT><UP> shortcut. START Codes may only be displayed in decimal or hex. If percent is selected for levels via SETUP OPTIONS, START Codes will be displayed in decimal. If hex is used, the display will show two hex digits followed by a lower-case 'h'.

5.7 SETTING THE MINIMUM LEVEL FOR SEARCHES

```
SEARCH MIN IS      1%
CHANGE IT ?
```

The search minimum is used by **VIEW LEVELS**. In **VIEW LEVELS** pressing and holding down the <DOWN> key and then pressing either <LEFT> or <RIGHT> will cause **VIEW LEVELS** to search the received slot table for next higher or lower slot with a level greater or equal to the search minimum. The number of slots with a level greater or equal to the search minimum is reported in the **RECEIVED SLOT SUMMARY DISPLAY**.

This menu item is used to set the search minimum. The range for the search minimum is 0 to 255. The search minimum may be displayed in decimal, percent or hex. The status may be changed by queries in the SETUP OPTIONS menu (see section 8.4). If percent is used the level is followed by a % sign. If hex is used, the display will show two hex digits followed by a lower-case 'h'.

5.8 DMX512 PARAMETERS NOT CHECKED

BAUD RATE - The MiniDMXter4 does not measure the baud rate of the received signal. Neither does it measure bit jitter. If the baud rate of the console is within the allowed range, the MiniDMXter4 should properly receive the signal, but no measurements are made or reported.

SIGNAL VOLTAGE LEVELS - The MiniDMXter4 does not measure the voltages provided on the EIA485 line, specifically neither differential nor common mode voltages are evaluated to see if they fall within the EIA485 specification. If the MiniDMXter4 is reliably receiving data, it is probable that the differential signal level is adequate. Testing of common mode signals is beyond the scope of the MiniDMXter4 and this manual. Both common mode and differential mode signals can be tested by a qualified technician using standard laboratory equipment.

5.9 RECEIVE TEXT PACKETS

A feature of DMX512-A is the TEXT PACKET. Today there are many DMX512 transmitters that are not large lighting consoles. Many devices designed for embedded applications require very little user interface *once they are configured*. However configuring or trouble shooting these devices is difficult at best. 'If only they had an LCD screen.'

The MiniDMXter4 and similar devices can be that screen. The present software provides two routines supporting Text Packet. This routine and a Text Packet transmitting routine in the transmit menu. Both routine use the same user interface. This routine can be used to monitor DMX512-A devices that support this feature.

```
|01234567890123456789|           |01234567890123456789|
|MS#  0 L-  0 C-  3|           |MS#  3 L-512 C-  3|
|■                                     |Alice was beginning |
```

The displays above are what you will see on entry to this routine. The left one is when you are not receiving test packets. On the right is what the display looks like when you are receiving a long text message. Shown is the third of the canned MiniDMXter4 messages. This message is the full packet length of 512 and we are looking at the beginning of the text. Details on required packet format and the currently supported messages are in Appendix A.

You can scroll through a message using the <LEFT> and <RIGHT> keys.

MS# DMX512-A allows a device to send up to 256 different text messages. They are numbered from 0 to 255. This routine generated up to 8 canned test messages. The above left screen is the first of canned message in the MiniDMXter4

L- Text message packets may have from 24 to 512 data slots, plus the START Code. (See the Appendix A) This field shows the length of the packet that is currently being transmitted.

C- This is the position within the packet of the character that is in the first display position on the second line of the display. As you use the <LEFT> and <RIGHT> keys to move about the display this number lets you know where you are.

Viewing the Text Packet- Moving about the Display

AUTO-INCREMENT: Hold down the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement the character position by one.

JUMP BY 10: Hold down the <BLUE> key and press the <RIGHT> or <LEFT> key to increment or decrement the character position by 10.

AUTO-INCREMENT BY 10: Hold down <BLUE> and then press and hold the <RIGHT> or <LEFT> keys to auto-increment or auto-decrement by 10.

RETURNING TO THE FIRST CHARACTER: Press both the <RIGHT> and <LEFT> keys to return the first character which is in slot 3.

VIEWING TEXT IN HEX: Press <UP> and <RIGHT>

5.9.1 Displayed Character

Many simple display units will not display all ASCII characters as clearly as you would expect. When you get to extended character sets used on PCs the results are very display dependent. Some displays including the one we use have provision to load what are considered 'non printing characters' with special displays. So if you see odd characters consult APPENDIX A.

6 CABLE TESTER

The MiniDMXter4 includes a cable test feature. While DMX512 cables may be tested by a conventional cable tester for continuity, testing them for ability to pass high speed digital data is a little more complicated. DC cable testers may pass as 'good' cables that will provide unreliable operation of DMX512.

We provide two modes of cable testing - double ended and single ended. Use double ended when you have both ends of the cable at hand; what you would do with a standard cable tester. Use single ended mode when you are testing an installed cable, where you don't have access to both ends at one time. This mode works by allowing you to take and store a sample of the signal at the console end of the cable you wish to test. It allows you to move the MiniDMXter4 to the other end of the cable and take a new sample. If the samples are the same, the cable is assumed to be good.

6.1 DOUBLE ENDED CABLE TEST

Upon entering the cable test menu, your first choice is whether you wish to do a double ended cable test. Selecting <BLUE> will bring you to the next question

CABLE TESTER
TEST PINS 4 AND 5?

Yes, we know, DMX512 doesn't use pins 4 and 5 - except that some manufacturers have found ingenious uses for them. So we give you the option of testing these pins. Our tests of pins 4 and 5 are for continuity only, and do not attempt to send digital data on these pins.

Answering <BLUE> will cause the test to start in a mode that tests all five wires. Pressing the <DOWN> key will cause the test to start testing only pins 1,2 and 3.

Once you begin the cable test, and assuming that your cable is good, the unit will step thru its procedure. After the unit has completed one test sequence the top line of the display will change to read CABLE GOOD! Each time the asterisk moves, the unit has completed one complete cable test and the cable has passed. A cable test consists first of checking for ground continuity, then checking for continuity and lack of shorts on Pins 2 and 3, then optionally continuity on Pins 4 and 5. Then a packet of DMX512-like data is transmitted and checked that it is received intact. If all of the above tests are successful, we consider the cable good. We move the asterisk one place in the display and start doing the test all over again.

Testing multiple cables: If you intend to test more than one cable at a time, after testing the first cable simply unplug it from the DMXter without pressing any keys on the MiniDMXter4. One of the error messages will appear, telling you that the 'cable' has failed. Plug the next cable to be tested into the unit and restart the test by pressing either the <UP> or <DOWN> keys. In this manner you may rapidly test multiple cables.

So it failed . . . If a cable fails the continuity test, the top line of the display will read

```
CABLE TEST FAILED
```

The text on the second line will tell you which pin(s) should be checked.

P1 : * means that Pin 1 (shield) is open. If Pin 1 fails, the test terminates so you will have no way of knowing if there are problems with other pins of that cable. We suggest that in repairing the cable, you check all the pins for problems. After repairing the cable test it again.

Some DMX512 users do not wire pin 1 on both ends of the cable. This cable tester will not test cables that do not have pin 1 connected on both ends.

P2 : * means Pin 2 open or that Pin 2 is shorted to Pin 1.

P3 : * means Pin 3 is open or that Pin 3 is shorted to Pin 1.

PINS 2&3 REVERSED! Obvious, huh?

P2 : * P3 : * means that either Pins 2 and 3 are both open or they are shorted to each other.

If either Pin 2 or Pin 3 is open or shorted to ground or the other pin, the test will stop before testing Pins 4 and 5.

P4 : * means Pin 4 is open or that Pin 4 is shorted to Pin 1.

P5 : * means Pin 5 is open or that Pin 5 is shorted to Pin 1.

PINS 4&5 REVERSED! Obvious, huh?

Px : * Px : * means that either both Pins are open or the pins are shorted together.

P2 : * P3 : * P4 : * P5 : * means that either the pairs Pin 2/Pin 3 and Pin 4/Pin 5 are reversed or Pin 2 is shorted to either Pin 4 or Pin 5, and that Pin 3 is shorted to Pin 4 or Pin 5. Pin 2 is not shorted to Pin 3 or the test would have stopped already.

If the data test part of the test fails, the display will read

```
CABLE TEST FAILED  
WON'T PASS DATA
```

This means that you have a fatal problem with your cable. It may pass DC but massive errors were encountered when high speed digital data was sent. This error stops the test. If you wish to try again, press the <UP> or the <DOWN> keys. If, on the other hand, occasional data errors are found which might be caused by an intermittent solder joint or a cable that is borderline for transmitting data, the top line of the display will read

```
DATA ERROR
```

Once you've found a data error, the top line will continue to read DATA ERROR. The test will continue to run and the bottom line of the display will flash a black bar for about a second each time you encounter a data error.

6.1.1 Ending Cable Test

To end cable test, press and hold the <BLUE> key for about one second. You will know that cable test has ended when you no longer hear the clicking noise. Release the key and you will see the following message

TEST SUSPENDED

You may now use the <UP> or <DOWN> keys to restart the test. Pressing <BLUE> will return you to

CABLE TESTER
DOUBLE ENDED?

7 SETUP OPTIONS

The MiniDMXter4 is intended to be versatile so we provide the opportunity for the user to set certain options that make life a little easier. These options affect more than one function or menu.

7.1 AUTO SHUTDOWN TIMER

If no keys have been pressed for 10 minutes, the **AUTO SHUTDOWN TIMER** (if enabled) turns the unit off.

```
| AUTO SHUTDN  ENABLED | | AUTO SHUTDN  DISABLED |  
|  DISABLE SHUTDOWN | |   ENABLE SHUTDOWN  |
```

Pressing <BLUE> reverses the state of the timer and displays the appropriate message. Pressing <BLUE> will not step you to the next menu entry; it just reverses the timer state. To step to the next menu item you will have to press <DOWN>. This will preserve the current state of the timer.

7.1.1 DISABLING THE AUTO SHUTDOWN TIMER

Plugging the MiniDMXter4 into an external supply, including a USB port, overrides the setting of AUTO SHUTDOWN TIMER. When plugged into external power, your MiniDMXter4 will continue to run until shut off. Plugging the unit into an external power source does not change the shutdown flag, it just prevents the unit from automatically powering down until the unit is unplugged.

7.2 BACK-LITE OFF OPTION

```
| BACKLIGHT ENABLED | | BACKLIGHT DISABLED |  
|  DISABLE BACKLIGHT? | |   ENABLE BACKLIGHT? |
```

Pressing <BLUE> switches between the two settings.

7.3 DISABLING THE BACKLITE TIMER

The next menu will be one of the following items.

```
| BACKLIGHT TIMER ON | | BACKLIGHT TIMER OFF | | BACKLIGHT TIMER ON |  
| AC ON -CHANGE TMR? | | AC ON -CHANGE TMR? | | | NO AC POWER INPUT |
```

If the MiniDMXter4 is running on battery, you will see the third display. If it is plugged in an external supply or to the USB port you will see the first or second display. When the unit is running on battery pressing <BLUE> has no effect. If the MiniDMXter4 is plugged in pressing <BLUE> will toggle the timer and the display.

When the back light is 'on' it will remain 'on' if the timer is 'off'. This can be useful when using the Mini to do repeated measurements that do not require any keys pressed between measurements. This setting will persist until cleared either by this menu or by the operation of the unit from battery.

7.4 NUMBER FORMAT OPTION

The next menu item is the **NUMBER FORMAT OPTION**. Certain numbers may be displayed in any one of three formats: decimal (DEC), percent (%%), or hexadecimal (HEX). Slot levels may be displayed in all three formats. Decimal or hexadecimal notations are available for the START Code and for the **FLICKER FINDER** compare limit. When the DMXter is set to percent mode the START Code and the **FLICKER FINDER** compare limit will be displayed in decimal. Slot numbers and timing information are available in decimal notation only.

```
DISPLAY DATA IN  
DEC ▶%%%◀ HEX
```

The current display format is the one pointed to by the filled arrows. To set the display format use <LEFT> or <RIGHT> keys to move the filled arrows so they point to the desired selection. The format will be set to

whichever format is marked when you exit by pressing either <UP>, <DOWN> or <BLUE>. The default for this option is percent.

7.5 OPEN LINE DETECTOR OPTION

The choice will depend on the current setting of this option. The unit is factory set to **OPEN LINE ENABLED**. Most users will want to leave this function enabled.

The **OPEN LINE DETECTOR** is a proprietary Goddard Design Co. circuit to overcome a potential problem with the parent standard of DMX512, EIA485. In EIA485 it is possible to intermittently receive data from a cable that does not have connection of all of its pins. This can throw you off when trying to track down problems. Since the chance of passing data intermittently on a cable exists, the MiniDMXter4 incorporates the **OPEN LINE DETECTOR**. This circuitry flags seemingly good data when all the pins are not connected.

There are some manufacturers and suppliers in the theatrical lighting field that have DMX512 cables that deliberately do not have pin 1 connected at both ends. Following upon majority interpretation of the DMX512 Standard this is a practice that Goddard Design Co. does not endorse. If the MiniDMXter4 is used on these cables the **OPEN LINE DETECTOR** will provide spurious 'bad cable' readings and so we provide the option to disable it.

The following functions use the **OPEN LINE DETECTOR**:

VIEW LEVELS - it is the feature we call 'BNW' for broken wire

VIEW PARAMETERS - error summary screen where it is also called 'BNW'

SINGLE ENDED CABLE TEST - the following message indicates that the error was caused by the open line detector

```
DATA ERRORS
PINS 2/3 MAYBE OPEN
```

DOUBLE ENDED CABLE TEST - it is inherent to this test and cannot be turned off. This test will not test cables where Pin 1 is not connected at both ends.

7.6 ENABLE BUMP ALL

The original DMXter software did not allow bumping all slots to full. Many installations lack the power service to handle everything at full at once, and we don't own a piece of any fuse or circuit breaker manufacturer. However, there are tests where bumping all slots is very useful. This menu item allows you to enable this feature. We still would caution that this feature should be used **with care**.

7.7 COPYRIGHT NOTICE - Author Credits

What more can we say.

7.8 FIRMWARE BUILD DATE

The date that software was built is listed here. Note this date is stored in an area of the EPROM that is not included in the checksum.

7.9 FIRMWARE CHECKSUM

This item reports both firmware checksum (in hex) and the code length. Both of these items are important if you are reporting software issue.

7.10 CLEAR MEMORIES

7.10.1 ERASE EEPROM

The E² memories are used to store persistent data such as ShowSaver shows and RDM table of device information. Other data such as the current display format are stored here. It is advisable to clear this memory after a software update. After clearing this memory the unit should be turned off, the <BLUE> key depressed and held, and the unit turned on. This will store certain default values.

7.10.2 ERASE FLASH

Certain large files are stored in flash memory. A backup copy of the code is also stored in flash memory, but this is not erased by this command. Using this feature is seldom necessary.

7.10.3 CLEAR RAM AND SHUT DOWN

This feature is primarily a factory test feature. The unit will shut itself down in the same manner that it would if it timed out from inactivity.

8 FLICKER FINDER

Running a cue causes DMX512 levels to change. When your console is sitting there not running cues, the levels should be constant. Sometimes they aren't and that's not an easy problem to diagnose and troubleshoot without a DMXter. Most of the time the flickering lamp is not caused by the console; it's the lamp, or the socket, or the dimmer. Once in a while it is the console or the DMX512 transmission line. Since all of us automatically suspect the piece of equipment we understand the least, the MiniDMXter4 allows you to do a quick diagnosis of your console and the transmission line - and lets you get out the ladder with a heavy heart, but a clear conscience.

To use **FLICKER FINDER** you will use the Mini to take a **SNAPSHOT** of the console's output and compare it to what the console is outputting a short time later. You can do this at the console end only, checking the console only. Or, if you have any reason to suspect the DMX512 cable, you can do it at either the console first, moving down to the dimmer end, or you can do the whole test at the dimmer end on the principle that a funky cable will not give you repeatable results. If you suspect a bad cable, we advise that you run **SINGLE ENDED CABLE TEST** first, as this will test certain cable parameters that **FLICKER FINDER** is not designed to test.

Be certain that the MiniDMXter4 is connected to the console's output, either at the console or at the dimmer end of the control cable. Set the console to output a stable cue (important-not a chase!) Set a real cue with real levels, not every channel at 00. If you suspect one mode is 'flickering', set the console in that mode.

Upon entering the **FLICKER FINDER** submenu, the first message is

```
TAKE SNAPSHOT OF  
CONSOLE'S OUTPUT?
```

Pressing **<BLUE>** causes it to record the snapshot.

A technical note: During the taking of the snapshot the DMX512 line is momentarily terminated. So there is a very brief moment when data is not passed thru to the DMX512 OUT connector. If the unit did not see a digital input, it will tell you so.

```
NO DIGITAL INPUT  
OR INPUT NOT DMX512
```

After correcting the problem, press the **<DOWN>** key to try again. After the snapshot is recorded, the next display will read

```
COMPARE LIMIT IS    4  
CHANGE IT?
```

The compare limit is the number of steps of change either plus or minus that are allowed before the MiniDMXter4 considers that a channel is changing or flickering. Note that one step is one part in 256; not one part in 100. The default compare limit is 4, but the user may set it from 0 to 64. The MiniDMXter4 will remember the last limit you set and only returns to the default upon hard power up. **Note** that the compare limit menu item **does not** support any of the multi key bump functions.

The compare limit may be displayed in decimal or hex. If percent is selected for levels, the compare limit will be displayed in decimal. The status may be changed by queries in the SETUP OPTIONS menu (see section 7.4). If hex is used, the display will show two hex digits followed by a lower-case 'h'.

If the previously set compare limit is satisfactory, you may bypass changing it by pressing the **<DOWN>** key. Pressing **<BLUE>** allows you to change the compare limit in a manner similar to changing START Code. When you have set the compare limit (or bypassed setting it) you will see the following message

FLICKER FINDER
AT END OF LINE?

Is the MiniDMXter4 the last DMX512 device in line or do you have a loop thru to other receivers? Answering this question starts the data comparison. The display will read

COMPARING INCOMING
DATA TO REFERENCE

As long as no errors are detected and the battery has sufficient charge, you will continue to see this message.

When an error is detected, the message will change to

ERRORS DETECTED
PRESS BLUE TO VIEW

The test continues to operate with no further indication of other errors, if any. So let the test continue to run for whatever period of time you want; 15 minutes, one hour etc. Pressing <BLUE> will show you a summary screen of the errors found.

3 SLOTS W/ERRORS
FIRST: 2 LAST: 216

It will show you the number of slots with errors (1-512). On the second line of the display you will see FIRST and a number representing the lowest slot with errors and LAST and a number representing the highest slot with errors. To see details of the slots, press <DOWN>. You will now see a display

SLT: XXX ERRS: XXXXX
L: XXX H: XXX R: XXX

This screen means: the number following SLT is the lowest slot with errors. The number following ERRS is how many errors accumulated for this slot; it may range from 1-65,535. The number following L is the lowest level outside the reference window that the slot went to. The number following H will equal the highest level outside the reference window. The number following R equals the reference value for this slot recorded when the snapshot was taken. It is possible for the L value to be higher than the R value if all the incoming levels are higher than the R value. Similarly it is possible for the H value to be lower than the R value if all the incoming levels are lower than the R value.

At this point pressing the <RIGHT> key will take you to an identical screen for the next slot with errors. Using the <LEFT> key will take you to the previous slot with errors. (If you are at the first slot with errors, the <LEFT> key will take you to the highest slot with errors.) Both the <LEFT> and <RIGHT> keys have auto-repeat functions. Holding the <BLUE> key while pressing either the <RIGHT> or <LEFT> key will jump you to the last slot with errors or the first slot with errors, respectively. At any time while viewing the detailed error screens, holding the <BLUE> and <UP> will temporarily redisplay the error summary screen.

When viewing either the summary or detailed error screens you may quit by pressing <BLUE>. This will return you to

FLICKER FINDER
TO MAIN MENU?

8.1 RE-ENTERING FLICKER FINDER

If you hit <BLUE> accidentally, do not despair! You may reenter **FLICKER FINDER** at three separate points. Pressing the <DOWN> key will offer you the chance to take a new snapshot. Pressing the <DOWN> key again offers you the chance to reuse the existing snapshot. Pressing the <DOWN> key a third time offers you the chance to view previous errors. Isn't that reassuring?

NO ERRORS RECORDED

You will see this display if:

the last time **FLICKER FINDER** was run, no errors were detected,
or if **FLICKER FINDER** has not been run since the on/off switch has been cycled,
or if you have run the **SHOW SAVER PLAYBACK**,
or if you have run the **MULTI CHANNEL MODE** send routines.

If during the data comparison section of the test you press <BLUE> before any errors are detected you will get the following message

```
TEST SUSPENDED
TO MAIN MENU?
```

If you wish to continue the test, press <DOWN> or <UP>. Pressing <BLUE> will return you to the main menu. Once errors are detected, the data comparison section of the test cannot be re-entered. Once stopped, restarting the comparison clears the error tables.

8.2 TECHNICAL NOTES ON FLICKER FINDER

Flicker Finder disables the power off timer while it is comparing incoming data regardless of the user setup. The backlite is turned off and left off as well; terminating the test by using <BLUE> turns it back on. During the comparison test, the only key on the MiniDMXter4 that is operational is <BLUE> If during the data comparison section of the test any slot records 65,535 errors the test will be suspended. The display will read.

```
| TEST STOPPED, ERROR |
| OVERFLOW. VIEW?   |
```

8.2.1 Low Battery Warnings During Flicker Finder

Low battery warnings are displayed in a slightly different way during the data compare test of **FLICKER FINDER**. **FLICKER FINDER** is a very processor intense task that cannot tolerate any interruption so a special battery warning was required. When the battery discharges to the point that the MiniDMXter4 would normally display the standard warning, the display changes from the one on the left to the one on the right. This display will be latched and will not change back to the normal display even if the MiniDMXter4 is plugged into AC power.

```
| COMPARING INCOMING |           | FLICKER FINDER |
| DATA TO REFERENCE |           | LOW BATTERY WARNING! |
```

Once the low battery warning is displayed, it will only change if errors are detected. If the errors are detected and you have a low battery warning, the display will look as shown below.

```
| ERRORS DETECTED |
| LOW BATTERY WARNING! |
```

9 SHOWSAVER™

The **ShowSaver**™² feature is intended to help your show if your console becomes disabled at a bad time.

Uses of ShowSaver

There are many occasions in setting up and in testing a lighting system where it is useful to have several defined lighting looks available to switch between. Also, when testing or servicing certain DMX controlled apparatus, such as color changers, it is often useful to cycle thru a few different settings. **ShowSaver** adds to your MiniDMXter4 the ability to record and save two shows, each having eight looks. These looks differ from the **SNAPSHOT** in that they are not overwritten when the DMXter is used to perform its usual diagnostic tasks.

And should some forklift operator cut your DMX cable, having a source of lighting cues small enough to left in one hand could be very useful (no, not to brain the klutz with! - the MiniDMXter4 isn't heavy enough - another reason you should have bought a DMXter4 RDM). Seriously though, while we do not wish you to view the MiniDMXter4 as a lighting console, **ShowSaver** is intended to serve as a backup when disaster strikes. Remember that this capability is useful only if you learn to use it before you need it, and you make a practice of using it during show setup!

² Show Saver, SHOW SAVER, and ShowSaver are trademarks of Goddard Design Co.

9.0.1 ShowSaver, Conventions and Structure

ShowSaver has two major subsections. The first section records or edits the stored scenes. The second section plays back scenes. The sections are separate, except that they share a common entry point. It is not expected that a user will switch back and forth between record and playback, so once you enter the **PLAYBACK SCENE** section the only exit takes you to the **MAIN MENU**.

ShowSaver has a convention that is peculiar to it. The **<LEFT>** and **<RIGHT>** keys are used to increment or decrement the current scene number. The routines that record or edit scenes share a common user interface. It is described in detail in sections 9.3.3 thru 9.3.5.

9.0.2 Selecting Playback or Record

On entering **ShowSaver**, the first choice we give you in the menu is to playback the previously stored scenes.

```
SHOW SAVER
PLAYBACK SCENE?
```

This may seem a little out of order, but think about it - your stage is in total darkness when it shouldn't be. How many menu items would you want to go thru to get light on the stage?

9.1 PLAYBACK

PLAYBACK SCENE is the only method to sequence thru the recorded scenes. Its operation is designed to be simple and we hope obvious, since you may not be at your calmest when using it. The behavior of **PLAYBACK** depends on whether you are connected to a transmitting source of DMX512 when you press the **<BLUE>** key. If you are connected to a transmitting source of DMX512, you will enter **MONITOR** mode. If the MiniDMXter4 does not see valid DMX512 within 1/4 second, it enters **PLAYBACK**. **MONITOR** is a useful mode of operation, but probably you should learn about **PLAYBACK** first. We'll tell you about **MONITOR** now, but you might consider skipping over it for now.

To enter **PLAYBACK** in any form, you must have scenes recorded. Otherwise, when you press **<BLUE>** you will be told

```
SHOW SAVER
NO SCENES RECORDED
```

This message is displayed briefly. If you see it, you will have to skip to section 9.5 to learn how to enter scenes.

9.2 DMX MONITOR MODE

The purpose of **MONITOR** mode is to attempt to preserve the last valid DMX transmission in case of disaster. The concept is that this will help you to make a smooth transition to the scenes stored in the MiniDMXter4. Remember that unless you **have** stored some scenes in the unit, this is useless to you.

The MiniDMXter4 must be daisy-chained between the console and the first dimmer rack. The console must be turned on and transmitting valid DMX512 to the dimmers. Select the **ShowSaver** menu and select **PLAYBACK SCENES?**. If the unit detects valid data, you will see the following display:

```
|STAGE: °_k GM: 100%|
|AUTO START ON FAIL ?|
```

In the field following **STAGE**: you will see a small 'ok' chasing rapidly. This indicates valid DMX reception. At this point the MiniDMXter4 is in pass thru mode. If you do nothing or if you press **<DOWN>** the unit will inform you of a failure but will not automatically start sending DMX. Pressing **<BLUE>** will enable the unit to start transmitting automatically on a failure of the console's DMX output. Pressing either key will change the display to the following.

```
|STAGE: °_k GM: 100%|
|NEXT: 1 TIME: 3|
```

While the MiniDMXter4 is in monitor mode the **<RIGHT>** and **<LEFT>** keys are active and you may preset the scene you wish to go to following the 'OK' scene in the event of a failure.

9.2.1 When the Monitor Mode Detects a Failure

If you have had the Mini in monitor mode for more than a minute, the display backlite will have timed out. If the MiniDMXter4 fails to detect valid DMX for one second, it holds the last valid transmission it received, turns on the display backlite and the display changes to one of the displays below.

```
| STAGE: FAIL GM: 100% |           | STAGE: ° ° ° GM: 100% |  
| NEXT: ° TIME: 0 |           | NEXT: 1 TIME: 0 |
```

This is meant to get your attention, assuming that what is happening to the lights on stage hasn't. If you enabled auto start, the display on the right will be shown. If not, the display to the left is shown.

9.2.2 If Auto Start Is Disabled

The MiniDMXter4 is not yet transmitting and we presume your console isn't either. If the console has stopped transmitting what you are seeing on stage now depends on your dimmers; **certain types will hold the last transmission for considerable time before fading to black, while others will dump immediately.** Your console is still connected to your dimmers via the DMX line; if you can still run cues the problem must have been transitory. On the other hand if your console is still transmitting, but erratically, you may get 'disco dimmers'. Now you have two choices (three really, if you count turning it all off and going out for coffee and then calling the shop . . .)

Choice 1 - Retest the DMX512 line: press the <UP> or <DOWN> keys, this will cause the DMXter to retest the incoming DMX line. If valid DMX512 has returned, the unit will return to monitoring the line. If on testing the line the MiniDMXter4 does not find valid DMX it will go into **ShowSaver** playback just as if you pressed <BLUE>.

Choice 2 - Go to playback: press <BLUE>. This will transmit the last stored transmission to the stage. We cannot guarantee that this look is not corrupt. It all depends on how the console failed. . . The display will read

```
STAGE: ° ° ° GM: 100%  
NEXT: 1 TIME: 3
```

The stored scene will bump to the stage. If your dimmers were holding level, you may see little change. If they were black . . .

During the time between 'FAIL' appearing and pressing the <BLUE> key to start transmission, the following apply:

- The console is still connected to the dimmers
- The MiniDMXter4 is neither receiving nor transmitting
- <BACK> serves its normal functions

9.2.3 If Auto Start Is Enabled

If you selected auto start on failure the MiniDMXter4 turns on its transmitter and sends the last look seen on stage to the dimmers. We cannot guarantee that this look is not corrupt. It all depends on how the console failed. . . The display will be the same seen above when you started the MiniDMXter4 transmitting by pressing <BLUE>.

```
| STAGE: ° ° ° GM: 100% |  
| NEXT: 1 TIME: 3 |
```

9.2.4 Now That You Are in Play Back Mode . . .

The scene in the **NEXT** field will be the lowest recorded scene unless you preset a scene while the MiniDMXter4 was in monitor mode. You are now in **PLAYBACK** and the rules apply. See below. Once you fade to another scene, the 'emergency' scene is gone.

9.3 ABOUT PLAYBACK

The following are several things that you should keep in mind when using **PLAYBACK SCENE**.

When you press <BLUE> entering **PLAYBACK**, if the MiniDMXter4 does not detect valid DMX within 1/4 second, the transmitter is turned on and the **BLACKOUT** scene is transmitted. Therefore, if any dimmers were on, they will be taken to black. To get lights up you must select a previously stored scene and press <BLUE>. This will start a cross fade into that scene.

Entering **PLAYBACK** disables the auto power timer so that you do not have to worry about the DMXter turning itself off on you. But you must consider the fact that it could run out of battery charge. In **PLAYBACK** the transmitter is always on, hence the drain on the battery is high. A MiniDMXter4 that is to be used as a back up must be kept well charged. The cues are stored in non-volatile memory. Keep your MiniDMXter4 well charged and if you are going to use it to drive dimmers for an extended period, plug it into external power.

Plugging the MiniDMXter4 into external power while it is running will cause the unit to reboot. So you do not wish to do this while running ShowSaver.

If you are in the active **PLAYBACK** mode, the <BACK> and the <RED> keys have special uses. Their special uses are explained below.

9.3.1 The Playback Display

Below is the playback display as it may look when you enter **PLAYBACK SCENE** for the first time. When you enter **PLAYBACK** the stage will be in blackout and the **NEXT:** scene will set to the lowest numbered scene that has been recorded, usually scene one.

```
STAGE: BLK  GM: 100%
NEXT: 1     TIME: 10
```

There are four fields in the display. They are:

STAGE: Shows which scene is being transmitted to the receivers. Scenes are 1 thru 8 and BLK, which stands for BLACKOUT.

GM: Shows the current setting of the Grand Master. It may be set from 0% to 100 %.

NEXT: Shows the scene that will be faded to the next time the cross fade is started. The user may select the scene number in this field with the <LEFT> or <RIGHT> keys.

TIME: Shows the recorded fade time into the next scene.

While a cross-fade is underway the display will change. The **TIME:** field changes to read **XFADE:** and starts to count down the fade.

```
STAGE: BLK  GM: 100%
NEXT: 1     XFADE: 9
```

9.3.2 Keys Used in Playback

The seven keys all have functions in Playback. The following list is a quick summary of their playback uses.

| | |
|----------------|--|
| <RIGHT> | Increments the scene number |
| <LEFT> | Decrements the scene number |
| <BLUE> | 1) Starts a cross fade into the next scene, 2) exits 'onstage' edit mode |
| <UP> | Raises grand master level |
| <DOWN> | Lowers grand master level |
| <BLUE> <UP> | Bumps to next scene |
| <BLUE> <DOWN> | Bumps to blackout scene |
| <LEFT> <RIGHT> | View summary screen (Press and hold) |
| <RED> | Enters the 'onstage' edit mode |
| <BACK> | Asks "ABORT Playback?" <BLUE> confirms |

9.3.3 The Cross Fader

The crossfader executes a dipless cross fade between the scene in the **STAGE:** field and the scene in the **NEXT:** field. The cross fade starts when the <BLUE> key is pressed and released. During a fade, holding down the <BLUE> key will cause the fade to stop temporarily. The time remaining in a fade is shown in the

XFADE: field. At any time pressing and holding the <BLUE> key and pressing the <UP> key will cause a bump to the next scene.

During a cross fade pressing <BLUE> <DOWN> does not cause a bump to black, unless the next scene is BLK (a blackout). The following keys are also locked out during a fade; <LEFT>, <RIGHT>, and <BACK>.

9.3.4 The Grand Master

The grand master is operated by the <UP> and <DOWN> keys. If one of these keys is held, it auto repeats. The value changes in 1% steps. The Grand Master is 'last in line' affecting stage value - if the Grand Master is set at 80%, a dimmer entered at 100% appears onstage at 80%.

9.3.5 The Onstage Editor

If you need to change the levels of a few slots while in **PLAYBACK SCENE** you can do so by using the onstage editor. Pressing <MORE> will change the display to the same display seen in **SEND/EDIT SNAPSHOT**. The present **STAGE** scene will be loaded and slot levels may be changed in the same way they are in **SEND/EDIT SNAPSHOT**. You exit the editor by pressing <BLUE>.

- These changes take place on stage immediately as you enter them.
- The levels seen on stage will be the levels shown in the display as proportionally mastered by the Grand Master.
- The changes are made only to the **STAGE** scene and are temporary. The next scene faded to will be unmodified and the changes will not be present when you return to the scene you modified.
- All the key combinations available in SEND/EDIT will work here. So you may use such functions as 'search for next channel with level' and 'bump to half'.
- Remember that the Grand Master value affects the actual dimmer level seen onstage.
- When you are running with a modified scene you are warned of this fact by the addition of a * to the **STAGE** scene number. (example below)

```
STAGE: 2*    GM: 100%
NEXT: 3     TIME: 10
```

9.3.6 Playback Summary Display

If you would like to see a summary screen of the **NEXT:** scene, hold down both the <LEFT> and <RIGHT> keys simultaneously. An example of a summary display is shown below. The top line starts with S : x, where 'x' is the current scene number. The rest of the top line displays the scene name, if any. The second line lists the number of slots with levels equal or greater than 1%, and the first and last such slot.

```
S : 2 THIS SCENE NAME
    10 SLTS    3 TO 510
```

9.3.7 Exiting Playback

To exit Playback, press the <BACK> key. You will be asked to confirm that you are aborting Playback. Until you answer <BLUE>, Playback will continue.

9.3.8 Technical Information about Playback

PLAYBACK including **MONITOR** receives and transmits data only on START Code 0. This is the normal 'dimmer' START Code. In most systems, START Code 0 is used for all show data. Most moving lights will operate on START Code 0. START Code 0 is often referred to as the Null START Code. Using **PLAYBACK** sets the START Code to 0. This setting remains when you exit **ShowSaver**. **PLAYBACK** transmission characteristics are set by a special 'flavor'. If you need information on what we mean by a DMX 'flavor', see section 4.7. The flavor we use for playback is the same as the default setting of the **USER C** flavor. This flavor is permanent and will not change if you make changes to **USER C**.

PLAYBACK FLAVOR USED FOR ShowSaver

| BREAK LENGTH | MAB | SLOTS | INTER SLOT TIME | MBB | UPDATE RATE |
|--------------|------|-------|-----------------|---------|-------------|
| 160µs | 20µs | 512 | 45µsE | 14843µs | 16.6 HZ |

9.4 ShowSaver Start Code & Line Termination

The receive and edit routines of **ShowSaver** temporarily change the START Code to which the MiniDMXter4 is set to the 'dimmer' START Code of 0. Exiting **ShowSaver** by way of the **TO MAIN MENU?** menu item will restore the START Code to the value you were using beforehand.

The MiniDMXter4 always terminates the line. When you enter the record mode, the unit is switched to pass thru mode so that you may see the look you are recording. It will stay in pass thru mode only while you are in the record mode.

9.5 RECORDING SCENES

ShowSaver's scenes can be recorded from the output of any DMX512 console in the same manner as **TAKING A SNAPSHOT**. They may also be entered slot by slot (painfully!). If you wish to do this, please see **EDITING SCENES** Section 9.7 below.

An important difference between the MiniDMXter4 and most lighting consoles is that the MiniDMXter4 deals in slots, not in channels. To translate a cue sheet to the MiniDMXter4 will require some thought (and an accurate copy of any softpatch). This is another reason why it is usually easiest to record from the console.

So then, connect the Mini to the output of your console. Normally you will do this by daisy-chaining with your dimmers so you can see on stage what you're recording. Set the console to output a look you want to save which need not be a cue.

The entrance message for recording a scene is, appropriately

```
SHOW SAVER
RECORD SCENE?
```

9.5.1 The Scene Select Display

When you press the <**BLUE**> key, you will see

```
RECORD SCENE?          RECORD SCENE?
>1< 2 3 4 5 6 7 8    or    ▶1◀ 2 3 4 5 6 7 8
```

The numbers 1 thru 8 are the eight scenes that **ShowSaver** can store. A set of brackets points to the currently selected scene. Solid brackets enclose a recorded scene; open brackets enclose a cleared scene. To select the scene, use the <**LEFT**> <**RIGHT**> keys to move the brackets to enclose the desired scene. If you would like to see a summary screen for a particular scene, hold down both the <**LEFT**> and <**RIGHT**> keys simultaneously. An example of a summary display is shown below. The top line starts with S : x, where 'x' is the current scene number. The rest of the top line displays the scene name, if any. The second line lists the number of slots with levels equal or greater than 1%, the first and last such slot.

```
S : 2 THIS SCENE NAME
10 SLTS 3 TO 510
```

These conventions will be used any time you see a display of this type.

9.5.2 Taking the Snapshot

Press <**BLUE**> to record. If nothing was previously recorded in the scene, the screen message will display briefly **TAKING SNAPSHOT**. If the scene had been previously recorded, you will see the warning **OVERWRITE SCENE 1 ?** with the second line displaying the alphanumeric name of the old scene. If you do wish to overwrite the scene, answer <**BLUE**> here. If not, use <**DOWN**> to cancel the operation.

9.5.3 Naming the Scene

After recording the scene, the screen will read

```
EDIT SCENE NAME?
```

The second line of the display provides space for a sixteen character alphanumeric name. If you have overwritten an old scene, the old scene name will be in the display. If you have recorded to a cleared scene this line will normally be blank until you enter the name. The exception is if the scene recorded had no slots with levels equal to or greater than 1% (4 hex) - the scene will automatically be named **BLACKOUT**.

To edit a scene name, first press **<BLUE>**. The cursor will appear at the first space of the name on the second line. Each press of the **<UP>** key will step you thru first the numbers 0-9, then the alphabet. Pressing the **<DOWN>** key steps you thru the same sequence backwards. When you have the right character, use the **<RIGHT>** and **<LEFT>** arrow keys to move the cursor. When editing an old name, you may clear a space by pressing **<UP>** and **<DOWN>** simultaneously and releasing them. To clear from the cursor to the end of the line, press **<UP>**, **<DOWN>** and **<RIGHT>** simultaneously. (Look, it's the only three key press in the unit, ok?!) When you like the name, press **<BLUE>**.

9.5.4 Setting the Fade Time

The next screen message is

```
FADE TIME IS 3 D
CHANGE IT?
```

This display tells you the fade time in seconds. If 'D' appears, the time shown is the default fade time. The default fade time is shipped set to three seconds. The default may be changed; see Section 9.8 below. If you wish to set a different fade time, press **<BLUE>** and the display will change to

```
FADE TIME IS 3
CHANGING FADE TIME
```

Fade time may be set from 0 to 30 seconds using the **<UP>** and **<DOWN>** keys. It is important to note that setting a fade time of 3 is different from having a default time of 3. A scene for which you have set a fade time of 3 will always have a fade time of 3 (until you edit that time in that scene) while a scene with a default time of 3 will change when the value for the default time is changed. Pressing **<BLUE>** removes the default and substitutes a recorded value. To return to the default value, press **<BLUE>** and **<DOWN>**. Exiting the fade time editor puts you back to the

```
RECORD SCENE?
▶1◀ 2 3 4 5 6 7 8 display.
```

To reach the next menu item, press **<DOWN>**.

9.6 CLEARING OLD RECORDED SCENES

```
SHOW SAVER
CLEAR SCENE?
```

Pressing **<BLUE>** will get you to this display

```
CLEAR SCENE?
▶1◀ 2 3 4 5 6 7 8
```

The conventions for manipulating this display are the same as for recording scenes. You will see

```
CLEAR SCENE X ? followed on the second line by the scene name
```

If you mean it, press **<BLUE>** one more time.

9.7 EDITING RECORDED SCENES

```
SHOW SAVER
EDIT SCENE?
```

Pressing <BLUE> will get you to this display

```
EDIT SCENE?
▶1◀ 2 3 4 5 6 7 8
```

The conventions for manipulating this display are the same as for recording scenes. You will see

```
LIVE MODE          or          BLIND MODE
EDIT SCENE BLIND?  EDIT SCENE LIVE?
```

If the Mini is at the end of the line this question is irrelevant. If you are connected to dimmers then you have the choice of seeing the scene as you are editing it or leaving the unit in the pass thru mode and editing blind. If the present mode is correct press <DOWN>. If you wish to change the edit mode press <BLUE>. Each time you press <BLUE> the edit mode and display will toggle to the other state.

When you press <DOWN> you will enter the edit slot screen. This display is exactly the same as the **SEND/EDIT SNAPSHOT** display, see section 4.6 if you are not familiar with it. When you have adjusted all the slots you wish to change press <BLUE> to exit. Next you will be given a chance to edit the scene name, followed by a chance to edit the fade time. The methods used are the same as those used by **RECORDING SCENES**, above.

9.8 CHANGING THE DEFAULT FADE TIME

```
FADE TIME IS    x
CHANGE DEFAULT TIME?
```

The default fade time is used as the fade time for the permanent blackout scene and for all scenes that do not have individual fade times recorded. The default fade time is shipped set to three seconds. It may be set from 0 to 30 seconds using the <UP> and <DOWN> keys. Once set it will retain its new value until reset. Press <BLUE> when you have the default fade time you want. Exiting the fade time editor puts you back to the <RECORD SCENE?> menu.

9.9 LOAD SHOW

The MiniDMXter4 lets you store 4 “shows” in flash memory. This display shows you the current show and the number of shows allowed. Optionally a show may be given a 20 character name. If the show was named, the name will be displayed here.

9.10 STORE SHOW

The Mini DMXter4 allows you to store and name 4 copies of the stored scenes. While they are only 8 cues long, we call them shows. This menu allows you to record and name a show. Naming is done by means of the string editor described in Section 17.

9.11 DELETE STORED SHOW

This menu item will allow you to delete one of the stored shows.

9.12 ERASE CURRENT SHOW

This erases the show that is currently accessed by ShowSaver. It does not erase one of the stored shows described above.

9.13 RETURNING TO THE MAIN MENU

9.14 PLAYBACK SCENE?

This is where you will be given another chance to playback scenes if you did not choose to do so upon entry. If you scroll thru the **ShowSaver** menu more than once this is where you will find the playback query.

9.15 GETTING A SUMMARY OF THE SCENES

```
SHOW SAVER
SCENE SUMMARY?
```

This last menu in **ShowSaver** is another way to get a scene summary. If you enter this routine you will see the following display

```
SCENE SUMMARY
▶1◀ 2 3 4 5 6 7 8
```

Now you could get a summary display by pressing both the <LEFT> and the <RIGHT> keys, but that display is only shown as long as you hold both keys. If instead you press <BLUE> you will get a latched summary display, as per the example below

```
S:2 THIS SCENE NAME
10 SLTS 1 TO 512
```

If you wish to view a summary for another scene you may increment or decrement the scene number using either the <UP> and <DOWN> keys or the <LEFT> and <RIGHT> keys. NOTE: When incrementing or decrementing, cleared scenes are skipped.

10 RDM CONTROLLER

In using RDM, the definition of the devices at either end is a bit different from that in straight DMX512. RDM uses controllers and responders. A controller sends out an RDM request; a responder receives this request and replies. An important detail to keep in mind is that a responder may NEVER reply unless it receives a request. An RDM system is controlled by the controller.

The RDM software accessed by the Controller menu allows the MiniDMXter4 to act like a controller, providing basic identification and configuration of RDM units. Even in a system with a RDM console, the MiniDMXter4 will be useful for troubleshooting and system set up. You will be able to discover the RDM devices in your system; retrieve their present configuration and capability; set their DMX slot address and personality. You will also be able to set certain other configuration settings. You will be able to retrieve any sensor information that the RDM devices in the system provide - one example is internal temperature; another is line voltage.

If you have purchased the Advanced RDM package, you will be able to see detailed packet histories and packet timing as well as a number of other features designed for developers and evaluators of RDM responders.

10.1 Discover Devices

Each RDM device has a unique 48 bit ID. This number serves as its address and must be discovered before a controller can communicate with the device.

10.1.1. Discover Newly Connected Devices

This item looks for all devices connected to the system since the last discovery. It will discover only new devices.

10.1.2. Discover All Devices

This item erases the table of devices and re-discovers all connected devices. This item should be used anytime you connect the Mini to a new rig.

10.1.3. Store Rig

A rig is a discovery table for a particular lighting setup. If you're working on more than one lighting setup on a regular basis, this simply allows you to load the Table of Devices (TOD) without doing a full discovery. The Mini stores 4 rigs; each rig can be named using the string editor described in Section 17.

10.1.4. Delete Rig

Betcha can guess this one all by yourself!

10.2 Select Current Device

This item lets you scroll thru the discovered devices. The current device will be displayed as 12 hexadecimal digits

```
|4744:XXXXXXXX "GD" |  
|Goddard 5 prt HUB V2|
```

The first 4 digits are the manufacturer's ID string, in this case 47,44 which is Goddard Design's ID. The next 8 digits are a unique serial number for that manufacturer. The last two characters are the manufacturer's ID converted to ASCII characters, if possible. The second line of the display is the device Model Description text.

By default the currently selected device will be set into its identify mode. However, this feature may be switched on or off by pressing both <Left> and <Right>. When pressed and released these keys will momentarily flash "ENABLED" or "DISABLED". Identify may also be set or cleared in section 10.10.1 (Identify Device When Selecting?)

10.3 Device Information

All RDM responders are required to return a minimum set of information about themselves. They can optionally return a great deal more. This menu item lets you view the required information along with some common optional information.

10.3.1. Device Model

```
|DEVICE MODEL 0040h|  
|DMX-4 |
```

This display shows a 4 digit hex model number and an optional text description provided by the manufacturer. They are two separate PIDS. You can move between the information menus with <DOWN> or <UP> keys. You can leave this sub menu at any time with the <BLUE> key.

10.3.2 Device Label

```
|DEVICE LABEL |  
|MY DMX/RDM TESTER |
```

This parameter provides a method of setting a descriptive label for each device. This may be used for identifying a dimmer rack number or specifying the device's location. This is an Optional PID.

10.3.3 Manufacturer Label

```
|MANUFACTURER LABEL |  
|DMXter4 RDM |
```

This parameter provides an ASCII text response of up to 32 characters with the Manufacturer name for the device. The Manufacturer name must be consistent between all products manufactured within an ESTA Manufacturer ID. This is an Optional PID.

10.3.4 Software Version Number & Label

```
|SOFTWR VER 00020410h|  
| SOFT V text label |
```

The 32 bit software version number is part of the required device information response. The text response is optional.

This parameter is used to get a descriptive ASCII text label for the device's operating software version. The descriptive 32 character text returned by this parameter is intended for display to the user.

10.3.5 Slot Address & Slot Foot Print

```
|DMX512 ADDRESS ###|  
|SLOT FOOTPRINT ###|
```

Hopefully the meaning of the DMX address is obvious. The slot footprint field specifies the DMX512 footprint (number of consecutive DMX512 slots required). Both fields are required.

```
10.3.6 Personality Count
| PERSONALITY ## OF YY |
| descriptive text    |
```

The numeric data is required; the descriptive text is optional. Many RDM parameters may be affected by changing personality.

```
10.3.7 Sub Device Count & Sensor Count
| SUB-DEVICE COUNT ### |
| SENSOR COUNT        ### |
```

Sub devices are yet to be widely supported. A sub device allows a RDM responder to contain a root or base device, and multiple sub devices which have separately addressable properties. The classic case for sub device is a dimmer rack where each dimmer is a sub device. This allows each dimmer to be individually patched, with parameters individually set. All sub devices will have an identical set of parameters.

A sensor reports such things as temperature and voltage measurements Another menu item will let you read the values of any sensors.

```
10.3.8 Product Category
| PRODUCT CAT.    7101h |
| TEST EQUIPMENT      |
```

RDM devices can report a Product Category based on the product's primary function. Product Categories are encoded as 16-bit values as defined in Table A-5 of the Standard. These are arranged so that the upper eight bits define a coarse product categorization, and the lower eight bits additional (optional) fine categorization."

```
10.3.9 RDM Protocol Version
| RDM PROTOCOL VERSION |
|           1. 0       |
```

Any reply other than the one shown would be from a newer version of RDM than this software is designed to decode.

```
10.3.10 Device Power State
| DEVICE POWER STATE |
|           NORMAL   |
```

```
10.3.10 Hour and Power Cycles
| DEVICE HOURS    501 |
| POWER CYCLES   24  |
```

```
10.3.11 Lamp Hour and Lamp Strikes
| LAMP HOURS      200 |
| LAMP STRIKES   35  |
```

```
10.3.12 Lamp State and Lamp On Mode
| LAMP STATE      ON  |
| LAMP ON MODE    OFF |
```

```
10.3.13 Supported PIDS
| DEVICE INFORMATION |
| SUPPORTED PIDS?   |
```

When you enter this item, the Mini requests the supported PIDs from the current responder. The display below is just an example of what you may see for the first optional PID. Under RDM only optional PIDs are reported to the Get SUPPORTED_PARAMETERS command.

```
|PID 0081h      1/ 24+|
|MFG LABEL      |
```

The display '1/ 24+' can be read as: this is the first PID of 24 that were in the response to the GET message. The '+' means that this message contained a ACK_OVERFLOW, which here means that there are still more PIDs that this responder accepts. For many reasons some responders may only be able to pack a limited number of PIDs into a single response. The <UP> and <DOWN> keys scroll you thru the list of supported PIDs. When you come to the end of the list and there was a ACK_OVERFLOW you will be offered the chance get another group of supported PIDs. As a point of information the SUPPORTED_PARAMETERS response could list up to 115 PIDs.

```
|--AT END OF LIST-- |
| GET MORE ITEMS?   |
```

10.4 Set DMX Address

```
|CHANGE ADDR TO:   1|
|modelID text     |
```

This item lets you change the DMX slot assignment of the current device. The model ID of that device is displayed. Note that you may use the <RIGHT> and <LEFT> keys to choose which digit to change.

10.5 Set DMX Personality

This item lets you select current personality while displaying the personality description.

10.6 Setup RDM Device

10.6.1 Set Device Label

```
|SET DEV LABEL    1/32|
|your text goes here |
```

This item lets you enter a device label string. The standard allows for strings up to 32 characters; it does not require that all devices support that long a string. Characters may be entered using the Mini's keys or by typing on a PC connected to the Mini by USB. Both upper and lower case and most ASCII characters are supported.

When entering from the unit's keys, string editor rules are followed (details are in section 17). To enter from the USB, launch the terminal emulator, then enter using the <BLUE> key.

On the PC you will see 'Enter a string:' Whatever is typed on the PC, up to 32 characters (or the <ENTER> key) will be used as a possible label. When the string is fully entered, 'DONE' will be printed on the PC. The string will now appear on the top line of the Mini display. The bottom line will ask 'SEND STRING TO DEV?'.
SEND STRING TO DEV?

10.6.2 Capture Preset

This parameter is used to capture a scene into a preset within the responder. The first display is a cursor menu that lets you enter a preset number. The number of scenes you can store in preset depends on the responder, and will normally be vastly smaller than 16 bits' worth. The Mini has no way of checking this number before it is sent to the responder. Start at one and work up. When done press and release the <BLUE> key and then press the <DOWN> key.

```
| UP    DOWN  WAIT | | UP    DOWN  WAIT |
|  .0   .0    .0 | | 5.0   10.0  120.0 |
```

The first display above is how it will appear on entry. The second display has values entered. Times are shown in tenths of a second. Remember what range of times is supported is beyond the scope of the standard.

10.6.3 Play Back Preset

```
|LEVEL  PRESET NUMBER|
| 100%                1 |
```

Enter the Level and the preset number into this cursor menu, then press and release the <BLUE> key and then press <DOWN>.

```
|  PLAYBACK PRESET  |
| PLAY PRESET #    1?|
```

Press <BLUE> to play; <DOWN> to move on.

```
|  PLAYBACK PRESET  |
|PRESET PLAYBACK OFF?|
```

Press <BLUE> to switch off the preset function.

```
|  PLAYBACK PRESET  |
|  PLAY ALL PRESETS?|
```

Press <BLUE> to start a 'show'; <DOWN> to move on.

10.6.4 Warm Reset

See responder data sheet for more information on what your product does.

10.6.5 Cold Reset

It is likely that this message will not be acknowledged.

10.6.6 Restore to Factory Defaults

Need we say more?

10.7 View Sensors

This is a submenu with 10 items. The first item lets you pick which of the sensors fitted on the current responder you wish to look at.

```
|SELECT SENSOR  0/ 10|
|sensor description |
```

Select the sensor you wish to look at with <UP> or <DOWN> and then press <BLUE>. (The following displays are just examples of what you might see.)

```
|#  1  VOLTAGE      |
|+ 12.1            VDC |
```

Sensor '1' is a voltage sensor; its current value is 12.1 volts DC. RDM requires that a sensor be stored as a signed number between -32768 and +32767. It then allows for a multiplier in the range of 10^{-24} to 10^{+24} . In the display above the responder returned the number 121 and the multiplier 10^{-1} . The multipliers for 10^{-2} thru 10^{+2} will be handled by placing a decimal point in the correct position in the display. Other multipliers will be identified by a standard abbreviation.

```
|#  2  VOLTAGE      |
|+12000  milli VDC |
```

This sensor reports a value of +12000 and a multiplier of 10^{-3} . This is displayed by the SI abbreviation milli. A list of the abbreviations used by the MiniDMXter4 is in 10.7.1. Multipliers with negative exponents use lower case abbreviations while ones with positive exponents use upper case abbreviations.

Range Minimum-Maximum Value:

```
|LOW <DETECTED> HIGH|          |LOW <DETECTED> HIGH|
|+11999          +12001 |          |  NOT AVAILABLE  |
```

These are signed 16-bit values that represent the lowest and highest values registered by the sensor. Support for this data is optional.

Range Minimum-Maximum Value:

```
| MIN <RANGE> MAX |
| + 0 +32766 |
```

These are signed 16-bit values that represent the lowest and highest values the sensor can report. A value of -32768 indicates that the minimum is not defined. A value of +32767 indicates that the maximum is not defined.

Normal Minimum - Maximum Value:

```
| MIN <NORMAL> MAX |           | MIN <NORMAL> MAX |
| +23000 +25000 |           | NOT AVAILABLE |
```

These are signed 16-bit values that define the lowest and highest sensor values for which the device is in normal operation. A value of -32768 indicates that the minimum is not defined.

A value of +32767 indicates that the maximum is not defined.

```
| 01234567890123456789 |
| RECORDED VALUE |           | RECORDED VALUE |
| +24031 |           | NOT AVAILABLE |
```

This is a signed 16-bit value that represents the value that was recorded when the last RECORD_SENSORS was issued. Support for this data is optional.

```
| SENSORS |
| RESET MIN/MAX |
```

```
| SENSORS |
| RECORD VALUE? |
```

```
| SENSORS |
| RESET ALL MIN/MAX? |
```

```
| SENSORS |
| RECORD ALL VALUES? |
```

10.7.1 Sensor Abbreviations

- milli Multiply by 10⁻³
- micro Multiply by 10⁻⁶
- nano Multiply by 10⁻⁹
- pico Multiply by 10⁻¹²
- femto Multiply by 10⁻¹⁵
- atto Multiply by 10⁻¹⁸
- zepto Multiply by 10⁻²¹
- yocto Multiply by 10⁻²⁴
- KILO Multiply by 10⁺³
- MEGA Multiply by 10⁺⁶
- GIGA Multiply by 10⁺⁹
- TERRA Multiply by 10⁺¹²
- PETA Multiply by 10⁺¹⁵
- EXA Multiply by 10⁺¹⁸
- ZETTA Multiply by 10⁺²¹
- YOTTA Multiply by 10⁺²⁴

10.8 SEND/EDIT DEVICE

```
| SLT 2/ 2 6@100% |
| FAN SPEED |
```

This item allows you to manipulate the slots of the currently selected RDM device. It also will display the slot label, if available. Note that slots are shown as an offset from the base slot for the device. So, the first slot will be slot 0. The above display shows the third slot of a device using 3 slots selected. The absolute DMX slot address is 6, and it is presently at a value of 100%. The value may be manipulated using the <UP> or <DOWN> keys. The relative slot within the device may be selected using the <RIGHT> and <LEFT> keys.

10.9 Edit Null Start Code Data

The MiniDMXter4 sends Null Start Code packets between RDM packets . Whether null start code packets are sent is controlled by an item in the RDM User Option Menu. This item allows you to edit the packet to be sent. It behaves identically to SEND EDIT in Transmit.

10.10 RDM User Options

10.10.1 Identify Device When Selecting?

```
| IDENTIFY ON SELECT |  
|     ►YES◄ NO     |
```

This controls whether the responder is set into the Identify mode while you are selecting it.

10.10.2 Do You Wish to Retry on Bad or Lost Packets?

```
|RETRY LOST/BAD PKTS |  
|►OFF◄ 1x 2x 3x 4x |
```

The default is off, and you have the ability to set the number of retries to a maximum of 4.

10.10.3 Do You Wish to Ignore Warning Messages On Discovery?

```
| IGNORE DISC WARNINGS |  
|     ►YES◄ NO     |
```

The warning messages for discovery will highlight many discrepancies from an “ideal” discovery. If discovery completes, you probably don’t need to know the gory details. However this parameter defaults to on, and we’d recommend leaving it that way.

10.10.4 Controlling When Qued Messages Are Fetched from a Responder

```
|GET Q-MSG ON ACK_TMR|  
|►OFF◄ GETs ONLY ON |
```

RDM allows for responders to bring important details of their status to the attention of a controller. It does this by the use of a queued message. It also allows a responder to say “I need more time”. It does this by use of an acknowledgement with a timer request, which is called an ACK timer. A responder may ACK timer to either a request for information (a GET) or as a response to a message that sets a parameter (a SET). This menu controls whether the Mini takes any automatic action to queued messages. The choices are OFF, Ask for Qued Messages on GETS only, or on both GETS and SETS.

10.10.5 Interleave Null Start Code Packets?

```
| INTERLEAVE NULL SC |  
|     ►YES◄ NO     |
```

By default the Mini sends at least two null start code packets between two RDM requests. This is a realistic, real-world environment. However, discovering a large rig will progress faster if only RDM commands are sent. It may also be useful to turn off null start code packets in certain diagnostic situations.

11 COLORTRAN PROTOCOL SUPPORT

The MiniDMXter4 may be ordered with support for the Colortran protocol (CMX). If you have ordered this option you will get the documentation for it. It may also be downloaded from our web site at www.goddarddesign.com/pdf_doc/cmx_man.pdf

12 THE CE MARK

The European Union has established certain requirements that most electronic equipment must conform to if they are used within the EU. It has established testing methods to determine that a unit does conform. Units that do conform may carry the ‘CE mark’.



If you have been seeing the **LOW BATTERY WARNING** message for some time, the unit will at some point shut down after first displaying this message for a few seconds.

MiniDMXter4 V3.00
MEAL PENALTY

The unit will turn itself off within 10 seconds.

13.3 BATTERY OPERATING TIME

| Table 13-1 Approximate operating times | |
|--|----------|
| In Main Menu | 36 hours |
| Receiving at end of line | 32 hours |
| Transmitting Mini default flavor | 22 hours |
| Transmitting other flavors | 15 hours |
| Receiving pass thru | 14 hours |

The operating times are based on using an Energizer E91 Zinc-Manganese Dioxide battery. Times also assume that the back light is on. They should be conservative, but as they say, your mileage may vary.

14 MiniDMXter4 TECHNICAL DISCUSSION

The following are discussions of a few items of interest that we couldn't find a better place to put.

14.1 MiniDMXter4 MAINTENANCE

Other than cleaning, the MiniDMXter4 requires no on going maintenance.

14.01 CLEANING

The exterior of the MiniDMXter4 may be wiped clean with a soft damp rag. The rag may be moistened with any mild water based cleaner. Do not immerse the unit. If any water enters the unit, let the interior dry fully before the unit is operated.

14.2 SPECIFICATION TABLES

| Table 14-1 Transmitted DMX512 Flavors | | | | | | |
|---------------------------------------|-------|------|-------|------|------|-------------|
| NAME | BREAK | MAB | SLOTS | IST | MBB | Updates/Sec |
| Mini STANDARD 10Hz | 100µs | 20µs | 512 | 21µs | 59ms | 10 |
| E1.11 (DMX512-A) | 92µs | 12µs | 512 | 0µs | 4µs | 44.08 |
| DMX512/1990 8µs MAB | 88µs | 8µs | 512 | 0µs | 4µs | 44.1 |
| 24 SLOTS 8µs MAB | 88µs | 8µs | 24 | 0µs | 4µs | 830.6 |
| DMX512/1990 4µs MAB | 88µs | 4µs | 512 | 0µs | 4µs | 44.1 |
| 24 SLOTS 4us MAB | 88µs | 4µs | 24 | 0µs | 4µs | 833.3 |
| 70µs BK 4µs MAB 20 S | 70µs | 4µs | 20 | 0µs | 4µs | 966 |
| Colortran Option | 215µs | 21µs | 512 | 2µ | 4µs | 26 |

BREAK = BREAK TIME

MAB = MARK AFTER BREAK
 SLOTS = NUMBER OF SLOTS
 IST = INTERSLOT TIME
 MBB = MARK BEFORE BREAK

| Table 14-2 RECEIVED DMX512 PARAMETERS | | | |
|--|-------------|---------|----------------------------------|
| FUNCTION | MINIMUM | MAXIMUM | NOTES |
| BAUD RATE | 250,000 | | as per DMX512 |
| BREAK LENGTH | 50 μ s | - | |
| MAB LENGTH | 3 μ s | - | |
| NUMBER OF SLOTS | 1 | 512 | OVFL reported for over 512 slots |
| BREAK-BREAK TIME | 170 μ s | 3 SEC. | |

| Table 14-3 ACCURACY | | |
|-------------------------------|-------------------------|---|
| PARAMETER | ACCURACY | NOTES |
| TIMEBASE & BAUD RATE ACCURACY | +/- 75 PPM | 0 - 70 Degrees C, by design, not tested in production |
| TRANSMITTED BREAK JITTER | NEGLIGIBLE | Timebase jitter is the major source of break jitter |
| TRANSMITTED MAB JITTER | NEGLIGIBLE | START Code = 0 BREAK + MAB less than 16.380 MSEC |
| TRANSMITTED MAB JITTER | -0 / +4 μ s | NON-ZERO START Code or BREAK + MAB time greater than 16,380MS |
| SLOT FRAME JITTER | +/- 2 μ s | |
| SCOPE TRIGGER TO BREAK JITTER | NEGLIGIBLE | Timebase jitter is the major source of jitter |
| REC'D BRK,MAB ACCURACY | +/- 250nS +/- 75PPM (1) | Sum of both errors, rounded as needed for display |
| REC'D BREAK TO BREAK | +/-8 μ s | See section 5.2.5 |

| Table 14-4 VOLTAGE AND CURRENT LIMITS | | |
|--|--------------------|----------------------|
| | VOLTAGE OR CURRENT | NOTES |
| EXTERNAL BATTERY ELIMINATOR | 5 - 10 VDC MAX | 5. VOLTS RECOMMENDED |

| | | |
|---|-------------------------------|--|
| DMX512-OUT PINS 2&3 MAX VOLTS MAX CURRENT ESD (human body model) | +/- 6.8 VOLTS 100mA 8KW | Withstanding voltage & current without damage. Mis-operation possible |
| DMX512-IN PINS 2&3(2) MAX VOLTS MAX CURRENT ESD (human body model) | +/- 12 VOLTS 100 mA 8KW | Withstanding voltage & current without damage. Mis-operation possible |
| PIN 4&5 IN or OUT | +35 VDC -25 VDC | |
| Resistance Pin 1 of I/O Connectors to Metal Case | 22 Meg Ohms | |

| Table 14-5 OPERATIONAL ENVIRONMENT LIMITS | | |
|---|-------------------------|----------------|
| PARAMETER | RANGE | NOTES |
| Humidity | 0% to-95% | Non-condensing |
| Altitude | 0 to 1900 meters | |
| Temperature | 0 to 40 Degrees Celsius | |

14.3 CONNECTOR FUNCTIONS AND CONNECTOR WIRING

The MiniDMXter4 supports bidirectional requirements of E1.20(RDM).

14.3.1 DMX-in

The male 5 pin connector is the DMX512 input connector. It is used for all DMX512 receive functions. When receiving, Pins 2 and 3 of the DMX IN connector are connected to a differential line transceiver. This line transceiver consists of a standard EIA485 transceiver chip protected by a transient and over voltage protection network. Pin 1 is the signal common and shield. It must be connected through to the signal common of the device under test for accurate results.

14.3.2 DMX-out

The female 5 pin connector is the DMX 512 output connector. It is used for all DMX512 transmit functions. Pins 2 and 3 of the DMX OUT connector are always wired to a DMX512 line driver. The line driver consists of an EIA485 transceiver and a protection network. When required, this connector has the RDM bias applied. The output is always terminated; this is not required for DMX512, but neither is it prohibited.

14.3.3 Topology for DMX Terminate & DMX Pass Through Modes

The DMX IN connector is always terminated. If a “pass through” mode is required, the output transceiver is enabled, and transmits a copy of the data from the input. Using this mode increases power consumption. If the MiniDMXter4 is turned off or shut down for low battery, it will cease passing through data.

14.3.4 Uses of Pins 4 & 5

The Cable Test routine tests the continuity of Pins 4 and 5. No other use is made of these pins, and they do not loop through.

14.4 THE PERCENT SCALE

We have included a percent display mode in the MiniDMXter4 for the convenience of having a display that approximates the display seen on your lighting console. The percent display mode should not be expected to exactly match any particular console, and should not be used if it is important to know the actual level that you are receiving. It should not be assumed that a MiniDMXter4 transmitting 45% percent will transmit the same code as your light console set to “45”.

DMX512 uses an 8-bit binary byte to represent a slot level. This means 256 possible levels, 0 to 255. Theatrical lighting has long used a 10 point scale, which with the advent of the digital control console, became a 101 point scale, 0 to 100. There is no integer factor to convert 101 to 256. Therefore an integer conversion between these scales will be approximate. There is no universal agreement on exactly how the rounding should be done. The discrepancies manufacturer to manufacturer are seldom of great import in theatrical lighting although they are of some import when DMX512 is used to drive other devices, such as color scrollers.

Technical note: The conversions from percent to decimal and decimal to percent in the MiniDMXter4 are all table driven. When the MiniDMXter4 is set to the percent mode more than one received code will be displayed as the same percent value. For example 7Fh, 80h, and 81h are all displayed as 50%. The full receive conversion table is listed below.

The RAM slot table always stores slot levels in 8-bit binary. Conversion is done when a number is displayed. Hence a snapshot is re-transmitted exactly as it was received. While 7Fh and 81h are both displayed as 50% they will be stored and re-transmitted as different levels. **BUT** when the MiniDMXter4 is in percent mode you can only enter one value for each percent step. To find the exact values see the transmit conversion table listed below.

There is an exception to the rule that changing display mode does not change data. The display resolution of hex and decimal is finer than that of percent. This means that there are two or three values of hex and decimal that are nominally displayed as 50%. If the DMXter has been set to hex and you have been searching for slots set to 80h (nominally 50%) and you switch the unit to percent, you would expect to find all slots displayed with a value of 50% or greater. Hence we change the search value from 80h to 7Fh so that all slots displayed as 50% are included. On changing from hex or decimal to percent, all search values are corrected so that all slots displayed as set to the same percent will be found.

14.5 PERCENT TABLES

| Table 14-1 | | | | | | | | |
|------------|-------|------|----|-------|------|----|-------|------|
| % | REC'D | XMIT | % | REC'D | XMIT | % | REC'D | XMIT |
| 0 | 00-02 | 00 | 34 | 57-58 | 58 | 68 | AD-AF | AF |
| 1 | 03-05 | 05 | 35 | 59-5B | 5B | 69 | B0-B1 | B1 |
| 2 | 06-07 | 07 | 36 | 5C-5D | 5D | 70 | B2-B4 | B4 |
| 3 | 08-0A | 0A | 37 | 5E-60 | 60 | 71 | B5-B6 | B6 |
| 4 | 0B-0C | 0C | 38 | 61-62 | 62 | 72 | B7-B9 | B9 |
| 5 | 0D-0F | 0F | 39 | 63-65 | 65 | 73 | BA-BB | BB |
| 6 | 10-11 | 11 | 40 | 66-68 | 68 | 74 | BC-BE | BE |
| 7 | 12-14 | 14 | 41 | 69-6A | 6A | 75 | BF-C0 | C0 |
| 8 | 15-16 | 16 | 42 | 6B-6D | 6D | 76 | C1-C3 | C3 |
| 9 | 17-19 | 19 | 43 | 6E-6F | 6F | 77 | C4-C5 | C5 |
| 10 | 1A-1B | 1B | 44 | 70-72 | 72 | 78 | C6-C8 | C8 |
| 11 | 1C-1E | 1E | 45 | 73-74 | 74 | 79 | C9-CB | CB |
| 12 | 1F-20 | 20 | 46 | 75-77 | 77 | 80 | CC-CD | CD |
| 13 | 21-23 | 23 | 47 | 78-79 | 79 | 81 | CE-DO | DO |
| 14 | 24-26 | 26 | 48 | 7A-7C | 7C | 82 | D1-D2 | D2 |
| 15 | 27-28 | 28 | 49 | 7D-7E | 7E | 83 | D3-D5 | D5 |
| 16 | 29-2B | 2B | 50 | 7F-81 | 81 | 84 | D6-D7 | D7 |
| 17 | 2C-2D | 2D | 51 | 82-83 | 83 | 85 | D8-DA | DA |
| 18 | 2E-30 | 30 | 52 | 84-86 | 86 | 86 | DB-DC | DC |

| | | | | | | | | |
|----|-------|----|----|-------|----|-----|-------|----|
| 19 | 31-32 | 32 | 53 | 87-89 | 89 | 87 | DD-DF | DF |
| 20 | 33-35 | 35 | 54 | 8A-8B | 8B | 88 | E0-E1 | E1 |
| 21 | 36-37 | 37 | 55 | 8C-8E | 8E | 89 | E2-E4 | E4 |
| 22 | 38-3A | 3A | 56 | 8F-90 | 90 | 90 | E5-E6 | E6 |
| 23 | 3B-3C | 3C | 57 | 91-93 | 93 | 91 | E7-E9 | E9 |
| 24 | 3D-3F | 3F | 58 | 94-95 | 95 | 92 | EA-EC | EC |
| 25 | 40-41 | 41 | 59 | 96-98 | 98 | 93 | ED-EE | EE |
| 26 | 42-44 | 44 | 60 | 99-9A | 9A | 94 | EF-F1 | F1 |
| 27 | 45-47 | 47 | 61 | 9B-9D | 9D | 95 | F2-F3 | F3 |
| 28 | 48-49 | 49 | 62 | 9E-9F | 9F | 96 | F4-F6 | F6 |
| 29 | 4A-4C | 4C | 63 | A0-A2 | A2 | 97 | F7-F8 | F8 |
| 30 | 4D-4E | 4E | 64 | A3-A4 | A4 | 98 | F9-FB | FB |
| 31 | 4F-51 | 51 | 65 | A5-A7 | A7 | 99 | FC-FD | FD |
| 32 | 52-53 | 53 | 66 | A8-AA | AA | 100 | FE-FF | FF |
| 33 | 54-56 | 56 | 67 | AB-AC | AC | | | |

14.6 STANDARDS - DMX512, EIA485

Detailed discussion of DMX512 is beyond the scope of this manual. We would recommend that persons wishing to know more consult a good book discussing asynchronous serial communications in computers.

The electrical standard on which DMX512 is based is EIA485. Many textbooks and catalogs discuss the features of this standard. It was issued by:

| | A copy of the DMX512 standard may be obtained from: | |
|---|---|--|
| Electronics Industries Alliance 2500 Wilson Boulevard Arlington, VA 22201-3834 USA ph: +1-703-907-7500 website: http://www.eia.org/ | Global Engineering Documents 15 Inverness Way East Englewood, CO 80112 USA ph: +1-800-854-7179 fax: +1-303-397-2740 website: http://global.ihs.com/ | ESTA 875 Avenue of the Americas (Rm.2320) New York NY 10001 www.esta.org |

14.7 RELEASE NOTES & SOFTWARE VERSION HISTORY

V3.00 is the first version of software released for this product. It is based on DMXter4 RDM V4.08.

15 FCC PART 15 STATEMENT

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

WARNING:

YOU MUST CORRECT ANY HARMFUL INTERFERENCE CAUSED BY THIS DEVICE.

This device is professional test equipment and as such it is not intended for residential use.

If this device causes harmful interference it is the responsibility of the user to take action to eliminate this harmful interference, and, if necessary, discontinue use of this device in the environment where the interference occurred.

16 USB OPERATIONS INCLUDING CODE UPDATES

Some functions on the MiniDMXter4 could use a bit more display space than 40 characters. Some current or future functions could benefit from a full keyboard. All the unit's running code is stored in flash ROM so we can email you a software update. The USB connector allows the MiniDMXter4 to be connected to any computer supporting a serial terminal emulator that connects via USB.

The USB port on the DMXter is not isolated .

16.1 Terminal Emulator Requirements and Recommendations.

The following are brief comments; for the most up-to-date recommendation, please check our website. <http://www.goddarddesign.com/usb2.html>

In general most terminal emulators which can be configured for serial communication via USB will work in a pinch. We do not recommend Hyperterm. Below are the basic requirements

| | |
|--------------|--|
| Baud rate | 57,000* |
| Word size | 8 bits |
| Stop bits | 1 |
| Parity | none |
| Flow control | none |
| Emulation | VT100 |
| COM port | depends on what USB com ports your machine has already assigned. |

* the USB interface on the Mini is of the FIFO style and runs at the USB buss speed; hence the baud rate setting is usually irrelevant. However most emulators will require that you enter a baud rate.

The com port supported will vary depending on what physical com ports are fitted and what USB com ports have been used by your computer before you first connected your MiniDMXter4 to it. It will always be at least com 3 and will often be a higher com port. For a method of removing unused com port assignments see the web page listed above.

16.2 Using a PC with Routines That Support USB

Launch the terminal emulator and select the com port immediately before entering the function that will use the USB.

16.3 Downloading new operating code to the MiniDMXter4.

If you are getting a software update for your MiniDMXter4, you must provide us with your correct serial number. Each update file is made for one and only one MiniDMXter4. It will be in the form of
xx.hex.serial_ number

* Put the code in a folder (directory) and open that folder in a small window.

* Turn on your MiniDMXter4 by holding down <UP><DOWN> keys. The display should then read

```
|Bootstrap v01 sn 16xx|  
| USB Not Connected |
```

“Sn 16xx” will be replaced with the serial number of your MiniDMXter4. Assuming you have USB serial drivers fitted on your computer, once you connect the USB cable between the MiniDMXter4 and the PC the display should change to:

```
|Bootstrap v01 sn16xx |  
| USB Connected 57.6k |
```

This means that the PC driver and the Mini's USB driver can talk. Now launch the terminal emulator.

* Start your emulator. See <http://www.goddarddesign.com/usb2.html> for more details.

* Once it is launched and you have configured it by selecting the right com port, you should start to see the following displayed on the PC.

Press "?" to connect

This message is repeated every few seconds until you comply. Then you will see the following:

S=Send New Code
E=Erase Flash
C=Checksum
B=Blank Check
R=Restore shipped code

To download the new code to your MiniDMXter4 you need to do the following steps

1. E - erase the current code.
 - * This will erase the operating software,
 - * Are you sure? (y/N)<Y>
2. B - Blank checks the memory that will hold the code. This is not required but is a check to make sure everything is ready. You should see: Firmware is Blank
3. S - Type " S" to send the new code. -
 - * Serial Number is 16xx
 - * Send .HEX file now (Control-C to abort):

Now open the provided hex file as the source of a download. How you do this will depend on the terminal emulator you are using. With some emulators you may need to open the file first. With the new version of Tera Term you can drag and drop the hex file into the emulator window.

17 THE STRING EDITOR

The string editor is used by several routines to enter labels and descriptive text. It is likely to be used by more routines in future releases. It allows you to enter or edit a string of up to 99 characters. Most strings are much shorter. Show names in ShowSaver are 18 characters long.

In most uses the end of the top line will display the current cursor position and the total allowed number of characters. i.e. 1/18 for ShowSaver shows. On entry the cursor will be under the first character of the display.

If before you enter the menu that uses the string editor, you have connected the USB terminal to the Mini, you will also be able to enter text from the keyboard of the terminal. On the PC you will see 'Enter a string:' Whatever is typed on the PC, up to the character limit (or when the <ENTER> key is pressed) will be used as text input to the menu.

Beyond the obvious key strokes there are several other editing key commands. All key functions are as listed below.

| | |
|-------------------|---|
| <UP> | Rolls thru the alphabet 0. . 9 , A .. Z and the punctuation |
| <BLUE> <UP> | Changes the case |
| < BLUE><DOWN> | Changes the case |
| <DOWN> | Rolls thru the punctuation - then Z thru A, 9 .. 0 |
| <UP><DOWN> | Enters a space. |
| <LEFT> | Moves the cursor to the left |
| <BLUE><LEFT> | Acts like a backspace key |
| <RIGHT> | Moves the cursor to the right |
| <BLUE><RIGHT> | Shifts characters to the right, inserting a space |
| <UP><RIGHT> | Clear to end of line |
| <DOWN><RIGHT> | Clear to end of line |
| <LEFT><RIGHT> | Return cursor to beginning of the display |
| <BLUE><DOWN> held | Asks if you wish to clear the string. |
| <BLUE> | Exits, saving text to the calling applications (menu) |
| <BACK> | Exits, saving text to the calling applications (menu) |

18 WARRANTY

The GODDARD DESIGN CO. warrants each unit it manufactures to be free from defects in material and workmanship under normal use and service for the period of 1 year from date of purchase. This warranty extends only to the original purchaser. This warranty shall not apply to fuses, disposable batteries (rechargeable type batteries are warranted for 90-days), or any product or parts which have been subject to misuse, neglect, accident or abnormal conditions of operations.

In the event of failure of a product covered by this warranty, GODDARD DESIGN CO. will repair a unit returned to us within 1 year of the original purchase provided the warrantor's examination discloses to its satisfaction that the product was defective. The warrantor may, at its option, replace the product in lieu of repair. With regard to any unit returned within 1 year of the original purchase said repairs or replacement will be made without charge. If the failure has been caused by misuse, neglect, accident or abnormal conditions of operation, repairs will be billed at a nominal cost. In such case, an estimate will be submitted before work is started, if requested.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS OR ADEQUACY FOR ANY PARTICULAR PURPOSE OR USE. GODDARD DESIGN CO. SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES WHETHER IN CONTRACT, TORT OR OTHERWISE.

If any failure occurs, the following steps should be taken:

1 Notify the GODDARD DESIGN CO. giving full details of the difficulty, and include the serial number. On receipt of this information service data or shipping instructions will be forwarded to you.

2 On receipt of the shipping instructions, forward the unit, shipping prepaid. Repairs will be made at the GODDARD DESIGN CO. and the unit returned, shipping prepaid.

All shipments to GODDARD DESIGN CO. should be made via United Parcel Service or similar 'best way' carrier prepaid. The unit should be properly packed either in its original container, or if in a substitute container, in one that is rigid and of adequate size to allow for suitable packing padding to protect the unit from shock.

The unit should be thoroughly inspected immediately upon original delivery to purchaser. All material in the container should be checked against the enclosed packing list. The manufacturer will not be responsible for shortages against the packing sheet unless notified immediately. If the unit is damaged in any way, a claim should be filed with the carrier immediately. Final claim and negotiations with the carrier must be completed by the customer.

APPENDIX A TEXT MESSAGE LISTINGS

```

** TEXT PACKETS
** The purpose of the ASC text packet is to allow equipment to
** send diagnostic information formatted for display.
** The START Code is 17h
** Packet length 3 thru 512
** (However for timing reasons most packets will should be padded to a
** minimum of 24 data slots.)
** Slot allocation is as follows:
**     slot 0: START Code 17h
**     Slot 1: Page number of one of the possible 256 text pages.
**     Slot 2: Characters per Line.
**           This Indicates the number of characters per line that the
**           transmitting device has used for the purposes of formatting
**           the text. A slot value of zero indicates ignore this field.
** Slots 3-512: ASCII text
**           All characters are allowed and where a DMX512 text viewer
**           is capable, it shall display the data using the ISO/IEC 646
**           standard character set.
** A slot value of zero (ASCII Null) shall terminate the ASCII string.
** Slots transmitted after this null terminator up to the reset sequence **
** shall be ignored.
*****

```

Text packets sent by the MiniDMXter4 are fixed. We allow for 8 messages.

Details of the MiniDMXter4 format are:

Slot 1 is set to 00h thru 08h to identify the current message.

Slot 2 is always sent as 00h.

Slot 3-511 are sent as ASCII text as required. After the last ASCII character is sent, a Null will be sent.

If fewer than 25 slots are sent, the packet will be padded out to 25 slots by whatever garbage is in the transmit buffer. These characters should be ignored.

Slot 512, if sent, will always be a Null.

In the listings below the text to be sent is delimited with single quotes (').

```

;text packet strings
;           |           1           2           3           4
TEXT_MS0   |1234567890123456789012345678901234567890
;
TEXT_MS1   DB   'MiniDMXter4 v3.00'
TEXT_MS2   DB   'COPYRIGHT GDC 2010'
TEXT_MS3   DB   'ESTA DMX512A TXT PACKET'
*           |           1           2           3           4
*           |1234567890123456789012345678901234567890
DB         'Alice was beginning to get very tired of'
DB         ' sitting by her sister on the bank, and '
DB         'of having nothing to do: once or twice s'
DB         'he had peeped into the book her sister w'
DB         'as reading, but it had no pictures or co'
DB         'nversations in it, "and what is the use '
DB         'of a book," thought Alice, "without pict'
DB         'ures or conversations?" So she was cons'
DB         'idering, in her own mind (as well as she'
DB         ' could, for the hot day made her feel ve'
DB         'ry sleepy and stupid), whether the pleas'
DB         'ure of making a daisy-chain would be wor'
DB         'th the trouble of getting up '

```

Message 4 below is most of the common punctuation listed in numerical order. Some displays may not provide readable results with all of these characters.

```

TEXT_MS4
  DB 021 ; ! (exclamation mark)
  DB 022 ; " (double quote)
  DB 023 ; # (number sign)
  DB 024 ; $ (dollar sign)
  DB 025 ; % (percent)
  DB 026 ; & (ampersand)
  DB 027 ; ` (single quote)
  DB 028 ; ( (left/opening parenthesis)
  DB 029 ; ) (right/closing parenthesis)
  DB 02A ; * (asterisk)
  DB 02B ; + (plus)
  DB 02C ; , (comma)
  DB 02D ; - (minus or dash)
  DB 02E ; . (dot)
  DB 02F ; / (forward sl

  DB 03A ; : (colon)
  DB 03B ; ; (semi-colon)
  DB 03C ; < (less than)
  DB 03D ; = (equal sign)
  DB 03E ; > (greater than)
  DB 03F ; ? (question mark)
  DB 040 ; @ (AT symbol)

  DB 05B ; [ (left/opening bracket)
  DB 05C ; \ (back slash)
  DB 05D ; ] (right/closing bracket)
  DB 05E ; ^ (caret/cirumflex)
  DB 05F ; _ (underscore)
  DB 060 ; ` (grave accent)

  DB 07B ; { (left/opening brace)
  DB 07C ; | (vertical bar)
  DB 07D ; } (right/closing brace)
  DB 07E ; ~ (tilde)

```

Message 5 is some common ASCII formatting characters. Many LCD displays do not interpret these characters as a dumb terminal would. Some displays, including the MiniDMXter4 allow custom characters to be mapped to these and other 'unused' codes. Care should be taken when choosing non alphanumeric characters.

```

TEXT_MS5:
  DB '<BS>'
  DB 07h
  DB '<TAB>'
  DB 09h
  DB '<LF>'
  DB 0Ah
  DB '<CR>'
  DB 0Dh

```

Message 6 sends a single character 'S' that is meant for testing the behavior of receivers when sent a very short string.

```

TEXT_MS6: DC 'S'

```

Message 7 tests the behavior when a short string is terminated by a null but additional characters are sent after the null. A properly set up display should see only the character 'T'. If you cursor over the null character, the

MiniDMXter4 will display the rest of the string; but if given the whole string, it will stop receiving at the null.

```
TEXT_MS7:  DC      'T',00h,'You should not see this message,'  
           DC      `it''s after a null'
```